


EN

PNR/PNE 73-83-104-124 - PNR 142SL



ORIGINAL INSTRUCTIONS



INSTALLATION, USE AND MAINTENANCE MANUAL



Rev. 04
02-12-2019

COMPANY WITH
QUALITY SYSTEM
CERTIFIED BY DNV GL
= ISO 9001 =

2019 – **Juop** – Azzano Decimo (PN)

Reproduction, electronic storage and dissemination, even partial, are prohibited.

Juop reserves the right to modify the products described in this manual without prior notice.

Any product names mentioned herein are the trademarks of their respective owners.

Contents

1. General warnings	pag.	4	SPARE PART DATA SHEET – PNR/PNE 73-83 D	24
1.1 Introduction		4	SPARE PART DATA SHEET – PNR/PNE 73-83 M	26
1.2 Spare part request		4	SPARE PART DATA SHEET – PNR/PNE 104-124 D	28
1.3 Warranty terms and conditions		4	SPARE PART DATA SHEET – PNR/PNE 104-124 M	30
2. Technical data	pag.	5	SPARE PART DATA SHEET – PNR 142 D	32
2.1 Dimensions and arrangements		6	SPARE PART DATA SHEET – PNR 142 M	34
2.2 Performances		8	SPARE PART DATA SHEET – PNR/E 73-...-124 HYD & ACCESSORIES	36
2.3 Usage limitations		8	SPARE PART DATA SHEET – PNR 142 HYD & ACCESSORIES	39
2.4 Sound pressure level		8	SPARE PART DATA SHEET – ACCESSORIES (OUT OF PRODUCTION)	41
2.5 Lubrication		8		
3. Safety and accident prevention	pag.	9		
3.1 General recommendations		9		
3.2 Intended use		9		
3.3 Conveyed fluids		9		
4. Installation	pag.	10		
4.1 Compulsory accessories		10		
4.2 Checking upon receipt		10		
4.3 Storing in the warehouse		10		
4.4 Handling and installation		10		
4.5 Mounting		11		
4.6 Vacuum – Pressure Line		11		
4.7 Overheating alarm (optional)		12		
4.8 Vacuum-pressure inverter: Remote control actuators		12		
4.9 Pump mounting – Drive connection		13		
5. Start up	pag.	16		
5.1 Pump starting-up		16		
5.2 Precautions when starting the system		16		
6. Maintenance	pag.	18		
6.1 Ordinary maintenance		18		
6.2 Extraordinary maintenance		18		
7. Malfunctions: troubleshooting	pag.	22		
8. Scarapping	pag.	22		
9. Accessories	pag.	23		

1. General warnings

1.1. Introduction

- This booklet contains the necessary instructions for a correct installation, running, use and maintenance of the pump, as well as some practical suggestions for a safe operating.
- The knowledge of the following pages will grant a long and trouble-free operation of the pump.
- Following the instructions below contributes to limiting pump repair expenses by extending its duration, as well as preventing hazardous situations, thereby increasing its reliability.
- If the pump is driven by an hydraulic motor please refer to manufacturer's specific manual.
- It is recommended to:
 - Read, understand and apply carefully the instructions before running the pump.
 - Keep the booklet at hand and have it known to all operators.
- Below is a brief description of the symbols used in this manual.



If these safety rules are not respected, operators can be injured and the pump or oilers damaged remarkably.



If these safety rules are not respected, the pump or system can be damaged.



Suggestions for an environment friendly use of the pump.



Useful information for an easy usage and maintenance of the pump.

• The graphic representations and photographs contained in this manual are there to illustrate the product in the parts that make it up and in specific operating phases. Though the model shown in the manual may differ from the one purchased, the operating principle at the base of the illustrated operating phase is the same.

• Every PNR/PNE pump has to be fitted with its own tag reporting the following data: Model, Serial number, Year, Max speed, Max pressure.

 MADE IN ITALY Jurop S.p.A. - Via Crosera, 90 - 33082 Azzano Decimo - PN (ITALY)		
MOD.		
SERIAL No.		
YEAR		
MAX PRESSURE (bar)		
MAX SPEED (r.p.m.)		

Pic. 1.1

1.2. Spare part request

- Use only **genuine spare parts** for maintenance and repairs. To order spare parts, provide the following details:

EXAMPLE:

a) The model of the pump (see pump tag)	PNR 104
b) The serial number of the pump (see pump tag)	K90001
c) A description of the parts (see parts list)	VANE
d) The quantity (see parts list)	n°5 pz
e) The code number of the part (see parts list)	16016 059 00

1.3. Warranty terms and conditions

- Compliance with the installation, use and maintenance instructions provided by this manual **is crucial for the recognition of warranty** against defective parts.

2. Technical data


- Sliding vanes vacuum pump injection cooled (PNR) or natural air-cooling (PNE). The PNR version is meant for heavy duty; the PNE version for normal use.
- Automatic oil lubrication of both bearings and sealings. Copper oil piping. Rear oil tank (PNR/E 73-83-104-124). Side oil tank (PNR142).
- The suction unit consists of a 4-way valve (which acts as flow inverter between the suction line and the discharge line) and of a suction one-way non-return valve, all integrated to the vacuum pump in a single in-built manifold.
- Built-in vacuum-pressure changeover valve. Pneumatic or hydraulic actuator are available.
- Transmission:
 - Direct with smooth or splined shaft.
 - Gearbox transmission (ASAE 1" 3/8) 540 or 1000 rpm, counter clockwise rotation.
 - With hydraulic motor.

STANDARD EQUIPMENT

- Sliding-vanes, air cooled **vacuum pump**.
- Asbestos-free **tangential vanes**.
- Automatic lubrication by means of a **volumetric pump** and an **oil tank**.
- Asymmetrical manifold with **check valve** installed on the pump inlet.
- Pivoting suction and exhaust **conveyors** in aluminum alloy.
- **Direct transmission** with smooth or splined shaft (ASAE 1 3/8").
- **Gearbox transmission** with smooth or splined shaft.
- **Counter clockwise rotation**.
- **Injection cooled** (PNR) or **natural air-cooling** (PNE).


AVAILABLE ON REQUEST

- **Clockwise rotation**.
- Transmission with **hydraulic motor**.
- Drive by means of mechanical drive from **Power Take Off**.
- **Pulley** for the belt drive.
- **Pneumatic actuator** for the vacuum/pressure changeover valve.
- **Hydraulic actuator** for the vacuum/pressure changeover valve.
- **Safety thermostat**.




2.1. Dimensions and arrangements

PNR/PNE Direct transmission




Mod.	A	B	B1	C	D	D1	E	E1	F	F1	G	H	I	L	M	N	O	P	Q	R	S
PNR73	295	309	284	153	232	207	299	297	83	60	-	16	396	270	230	496	339	147	35	38	10
PNR83	317,5	331	306	153	255	230	322	319,5	83	60	-	16	396	270	230	496	339	147	35	38	10
PNR104	321	329	313	153	253	238	320	320	83	67	67	16,5	368	285	249	534	367	167,5	40	43	12
PNR124	353,5	362	346	153	285	269	352	352	83	67	67	16,5	368	285	249	534	367	167,5	40	43	12

PNR/PNE Gearbox transmission



Mod.	A	A1	B	C	D	E	F	G	H	I	L	M	N	O	P	Q
PNR73	668	733	372	153	296	84	-	16	396	270	230	558	496	339	45	62
PNR83	715	782	395	153	318	84	-	16	396	270	230	558	496	339	45	62
PNR104	727	791	406	153	329	85,5	67	16,5	368	285	249	600	534	367	50	62
PNR124	792	856	437	153	368	85,5	67	16,5	368	285	249	600	534	367	50	62

PNR/PNE Hydraulic motor




Mod.	A	B	C	D	E	F	G	H	I	L	M	N	O	P1	P2
PNR73	843,5	548,5	153	472	-	16	124	237,5	396	270	230	496	339	1" ¼	1"
PNR83	892	571	153	495	-	16		237,5	396	270	230	496	339	1" ¼	1"
PNR104	907	586	153	510	67	16,5	136	258	368	285	249	534	367	1" ½	1" ¼
PNR124	955	502	153	525	67	16,5	144	258	368	285	249	534	367	-	-

PNR 142 Side oil tank

PNR142 M (540-1000RPM)

PNR142 D

PNR142 HDR



WEIGHT	PNR/PNE 73	PNR/PNE 83	PNR/PNE 104	PNR/PNE 124	PNR 142 SL
Direct transmission (smooth or splined shaft)	110 Kg	119 Kg	150 Kg	170 Kg	210 Kg
Gearbox transmission (540 rpm)	121 Kg	128 Kg	173 Kg	185 Kg	225 Kg
Gearbox transmission (1000 rpm)	121 Kg	128 Kg	173 Kg	190 Kg	230 Kg
Hydraulic motor	141 Kg	155 Kg	185 Kg	200 Kg	225 Kg

2.2. Performances

Performances		PNR/PNE 73	PNR/PNE 83	PNR/PNE 104	PNR/PNE 124	PNR 142
Maximum speed	PN...D rpm	1350	1350	1300	1300	1200
	PN...M rpm	540	540	540 - 1000	540 - 1000	540 - 1000
	PN...HDR rpm	1350	1350	1300	1300	1200
Air flow at free air condition	l/min	7200	8200	10400	12400	14200
	m³/h	432	492	624	744	852
Air flow at 60% vacuum rate	l/min	6600	7600	9400	11200	12800
	m³/h	396	456	564	672	768
Maximum vacuum	%	93	93	95	95	95
Maximum vacuum at continuous duty PNR	%	70	70	70	70	70
Maximum vacuum at continuous duty PNE	%	60	60	60	60	-
Power required at free port	kW	6,5	7,5	9	11	14
Power required at maximum vacuum	kW	9,5	10,5	12,5	14,5	17
Power required at 0,5 bar rel (1,5 bar abs)	kW	11	12,5	14	16	20,5
Power required at 1 bar rel (2 bar abs)	kW	13	14,5	18,5	21,5	27,5
Max operating rel. pressure (abs.) at continuous duty	bar	1 (2)	1 (2)	1 (2)	1 (2)	1 (2)
Max operating rel. Pressure (abs.)	bar	1 (2)	1 (2)	1,5 (2,5)	1,5 (2,5)	1,5 (2,5)
Oil consumption	g/h	110-130	110-130	130-150	130-150	160-170
Oil tank capacity	l	2,2	2,2	3,2	3,2	4

REFERENCE CONDITIONS

Conveyed gas: air

Ambient reference temperature: 20°C (68°F)

Absolute reference pressure: 1013mbar (14.7psi)

Vacuum condition: atmospheric discharge

Pressure condition: atmospheric suction

Actual performance may vary of ± 5%

2.3. Usage limitations

Model	Max. Speed (rpm)			P (bar ABS)	T (°C)		Room Temperature
	Direct - HDR	Mult - 540	Mult - 1000		PNR	PNE	
PNR / PNE 73	850 - 1350	360 - 540	-	2,5 bar abs	180 °C	160 °C	-20 / +40°C
PNR / PNE 83	850 - 1350	360 - 540	-	2,5 bar abs	180 °C	160 °C	-20 / +40°C
PNR / PNE 104	850 - 1300	360 - 540	650 - 1000	2,5 bar abs	180 °C	160 °C	-20 / +40°C
PNR / PNE 124	850 - 1300	360 - 540	650 - 1000	2,5 bar abs	180 °C	160 °C	-20 / +40°C
PNR 142	850 - 1300	360 - 540	650 - 1000	2,5 bar abs	180 °C	160 °C	-20 / +40°C

P: absolute pressure during delivery

T: temperature during delivery

2.4. Sound pressure level

Lw (A)										
Noise power of the only pump, without drive transmission suction group, mufflers.			[dB(A)]							
RPM	VACUUM/PRESSURE	PNE 73	PNR 73	PNE 83	PNR 83	PNE 104	PNR 124	PNE 124	PNR 124	PNR 142
NOMINAL SPEED	vac 80%	90	92	90	92	90	93	90	93	94
	Δ press 0,6 bar	103	103	103	103	104	104	104	104	105

2.5. Lubrication

Recommended oils and greases: *OIL TANK*

Room T	Viscosity	Type	ENI	ESSO	SHELL	TOTAL	MOBIL	BP	TEXACO HAVOLINE
< 10°C	ISO VG 46	Mineral Oil	Acer 46	Nuto 46	Morlina oil 46	Drosera MS 46	Nuto H 46	Bartran HV 46	Rando HD 46
> 10°C	ISO VG 150	Mineral Oil	Acer 150	Nuto 150	Morlina oil 150	Drosera MS 150	Nuto H 150	Bartran HV 150	Rando HD 150

Recommended oils and greases: *GEARBOX*

Viscosity	Type	ENI	ESSO	SHELL	TOTAL	MOBIL	BP	TEXACO HAVOLINE
ISO VG 220	Mineral Oil	Blasia 220	Spartan EP 220	Omala oil 220	Carter EP 220	Mobilgear 630	Energol GR XP 220	Meropa 220

3. Safety and accident prevention



Attention: carefully apply these prescriptions.

3.1. General recommendations

- When transporting the compressor use proper slinging. Store the compressor in stable places.
- Installation and maintenance must be carried out with the unit totally disengaged from its drive system and must be performed by qualified personnel.
- Use adequate clothing (avoid ties, loose sleeves, necklaces and so on) and suitable protection equipment (gloves, protection glasses, boots...).
- Before each maintenance operation, stop the pump and restore the atmospheric pressure.
- Make sure that all the parts of the unit are idle and cool, before performing any maintenance operation.
- To prevent errors and hazardous situations, establish what each operator is responsible for in the different maintenance operations.
- Do not start the machine if the protection devices provided for transmissions are removed. Replace damaged part.
- Final manufacturer must make the transmission inaccessible by means of a fixed guard or interlocked movable guard.
- Operators working nearby must avoid prolonged exposure to the noise emitted by the aspirator, if not equipped with the proper ear-protection devices (IPDs recommended: ear protectors).
- When the pump is running, some parts may reach very high temperatures (above 70°C). Use all necessary precautions to avoid contact.
- Avoid accidental suction of solids: solids may be projected at high speed through the exhaust manifold and cause injuries. A filter must be mounted on the suction line (Mesh 55).
- Pressure relief valve: point the air flux away from the operators.
- Do not use the aspirator over its designed limits: the machine may be damaged and the operator may be injured.



Do not exceed the speed and the power supply parameters indicated in the technical tables (see par. 2.2 - 2.3).

- Based on the final use of the decompressor, the insertion in the housing machine and the typology of the same, the designer of the housing machine must apply safety signals (pictograms) to warn the operator on the risk still present. These pictograms essentially refer to three categories:

- Signals prescribing the use of Individual Protection Devices (IPDs) such as, in this case, the use of gloves and ear protectors.
- Signals indicating to pay particular attention to the dangers related to the machine's components, such as: risk of dragging in the transmission equipment and contact with hot surfaces.
- Signals indicating specific parts of the machine for an easier identification, such as: greasing points, oil tanks, etc.

3.2. Intended use

- Vacuum pumps of the PNR/PNE series are commonly used on stationary or mobile equipment for suction and transfer by means of vacuum or so-called pneumatic-transportation of liquid and solid wastes. Any other usage shall be considered improper.
- They are air-cooled and consequently foreseen for a non-continuous duty. The mod. PNE and the mod. PNR, the latter supplied with air injection system (fig. 1) and meant for heavy duty works, do not accept operating temperatures over 150 °C (300 °F), checked at not more than 150 mm from the discharge connections.
- Do not suck toxic substances and inflammable or explosive gasses, since the internal components of the pump may reach high temperatures.



Avoid suction of toxic (poisonous) explosive or flammable gasses because internal components may reach high temperatures.

- Avoid suction of liquids or solids, they can seriously damage the pump.




Attention: liquids or solids infiltrations can seriously damage the pump.

- Do not run the pump over its designed operating limits (see par. 2.3): it may break and transmission can be damaged.

3.3. Conveyed fluids

- PNR/PNE are suitable for conveying filtered air. Before conveying other kind of gases, verify compatibility with pump's characteristics.
- The machine was not designed and built to operate in environments with potentially explosive atmosphere (outdoor or indoor).
- Please contact JUROP's Technical dept. if necessary.

4. Installation



Pic. 4.1

Main components legend

1.	Vacuum/Pressure change-over valve	10.	Air injection valves (PNR)
2.	Non-return valve (Intake manifold)	11.	Drainage hole
3.	Vanes inspection port	12.	Exhaust conveyor
4.	Oil tank	13.	Suction conveyor
5.	Oil filling port and dip stick	14.	Pressure relief valve port. <i>Available only if foreseen with additional conveyor Code1627102500</i>
6.	Gear box oil filling plug	15.	Vacuum control valve set up
7.	Gear box oil level plug	16.	Safety thermostat (optional)
8.	Drip oilers		
9.	One way valve		

4.1. Compulsory accessories

- Compulsory accessories for a correct running of the pump:
 - Safety filter mounted between the pump and the secondary shutoff.
 - Over-pressure safety relief valve.

4.2. Checking upon receipt

- When the goods are delivered, make sure that all parts listed on the delivery note are in perfect condition and have suffered no damage during shipping.
- Remove the parts of the packaging that can be dangerous if sucked by the compressor.
- Make sure the vacuum pump has its identification plate. Pumps without such identification are to be considered anonymous and potentially dangerous: in such an event, they must not be used, otherwise the manufacturer will be deemed free from any liability whatsoever.

4.3. Storing in the warehouse

- If the compressor will not be installed inside a short time after delivery:

- Remove the guards from the ports and spray a film of protective oil over the inner surfaces of the body, rotors and sides. Then attach again the guards;
- Store in a closed and dry place. Renew the preserving oil periodically.
- To temporarily store a used pump, follow the instructions below:
 - Thoroughly clean the pump.
 - Equip the pump with suitable anti-corrosion protection.

4.4. Handling and installation

- Before each movement, verify that the lifting equipment has a suitable capacity (check the weight of the decompressor, possibly showed in this manual, in the paragraph 2.1).
- Do not lift the packaging or the machine when moving more than 50 cm from the ground. Proceed with the final lifting only near the installation point.
- Harness the machine with suitable straps / chains near the main body, paying attention to the position of the mass centre of gravity to ensure the load stability.




Warning: do not stand under the machine when it is lifted during the installation.

4.5. Mounting

- The pump must be assembled for an easy access for maintenance operations and secured rigidly to a frame or levelled base (max. 3° slant to the horizontal plane. See Fig. 4.1). The base must be such as to avoid vibrations, bending or deformation.
- It is recommended to install the pump on vibration adsorbing pads to reduce the noise and vibrations produced during its operation.
- Leave enough space around the pump to allow the free circulation of air for cooling; avoid exposure to dirt and debris.
- Provide the necessary space to reach all points of lubrication control (oil level), and the oil tank filler cap, the lever of the 4-way switch, vanes inspection ports. See Pic. 4.1.
- For PNR/PNE 73-83-104-124 the oil tank is mounted on the rear side of the pump. Instead for PNR142 the oil tank is mounted on the suction side of the housing.
- Provide for suitable manoeuvring spaces of the inverter lever. The control lever has two possible switching positions well defined by the latches and numbers reported on the fusion. It is directly connected to the internal diverter tang of the inverter, making it very intuitive: 90° of the lever switching corresponds to 90° of the inverter switching.
- Based on the functionality of the system which will house the decompressor, the designer of the end machine, must:
 - Properly signal the functionality of the inverter according to the position of the manual operating lever or of the pneumatic actuator or of the hydraulic one.
 - Install suitable pressure and / or vacuum restrainer valves near the inlet and outlet points of the machine.
- In case of PNR/PNE with hydraulic motor, provide the necessary space to disassemble the motor itself and proceed with joint lubrication.
- In the event that the decompressor is electrically isolated, connect it to the ground or make it equipotential with the housing machine. Check that the paint does not prevent its passage.
- The machine expels gas during delivery at temperatures that can reach the maximum permitted values for operation, with its lubricating oil in suspension. Oil consumption is stated in paragraph 2.2, the quantity of consumed oil corresponds to the quantity of oil emitted at delivery.

4.6. Vacuum / Pressure line

- See the following picture.
- The hoses connecting the suction and exhaust ports of the vacuum pump must be of adequate diameter (suggested not less than 3") and of oil and corrosion resistant materials and before connecting them, make sure that they are perfectly clean in the inside.
- The weight or dimensions of the pipes must in no way stress the PNR/PNE body. Use high temperature resistant rubber sleeves.
- Remove the port guards when mounting. The pipes and components of the whole line must be clean.
- Avoid constrictions and tight curves where they are not essential.
- Connect the pump to the tank through the suction manifold which has a threaded port for fitting the over-pressure valve.



Pic. 4.2

Vacuum / Pressure line components

1.	Primary shutoff
2.	Secondary shutoff
3.	Suction filter
4.	Silencer /
5.	Over-pressure safety relief valve
6.	Vacuum control valve


- The exhaust pipes can reach high temperatures. Protect those adequately from the operator reach.
- A clapet valve on suction pipe avoids rotation in the opposite direction when the pump stops.
- To avoid that foreign liquids will enter the vacuum pump it is necessary to mount on the suction line an over-flow valve of "floating-ball" type (Fig. 4.2 - pos. 1). The flow section of this valve must be equivalent to the suction hose's one.
- It is also necessary to have on the line a suitable air filter for preventing solids to be sucked inside the vacuum pump. It is also recommended to mount a "secondary shutoff" of floating-ball type (Fig. 4.2 - pos. 2) between vacuum pump and over-flow (primary shutoff), along with the previously mentioned air filter (Fig. 4.2 - pos. 3).
- Called also 4-way valve, normally is manually operated but it can be at any time transformed in pneumatically or hydraulic operated upon request of the appropriate kit.
- During normal running of the pump the resulting noise should be reduced by means of a suitable silencer (Fig. 4.2 - pos. 4) mounted as close as possible to the pump itself. It has to be dimensioned for the air flow produced by the pump model. The oil used for the pump's inside lubrication has to be separated from the exhausted air by means of an adequate oil-separator, placed directly inside the silencer. The silencer is fitted also with a draining tap for the collected oil and condensed liquids.



Do not dispose of in the environment. Dispose of in compliance with the standards in force.

- Over-pressure safety relief valve (Pic. 4.2 - pos. 5). It must be dimensioned to discharge the entire air-flow of the pump. The adjustment of this valve has to be kept inside 10% of tolerance of the pump's working pressure and in any case it has to stay inside the given value of the tank's work pressure.

- Vacuum control valve has to be fitted on the suction piping, if the tank's characteristics or the vacuum line will need this kind of vacuum-limiting device.



Pic. 4.3

- For pumps that reach, during normal operating, discharge air temperature close to 160-180 °C (320-360°F) - (checked at not more than 150 mm from the discharge connection) it is necessary to use a device (overheating limiter) that will not allow to exceed such temperature. Contact our Technical Department.

- An adjustable curved pipe is installed on the outlet of the silencer, in order to prevent rain from entering and to enable positioning (during installation) of the output airflow.

- An oil-separator must be installed in correspondence of the discharge line of PNR/E. Besides reducing the noise produced by the air flow along the vacuum line, the silencer also traps the oil vapour at the outlet due to decompressor lubrication.



Attention: an oil-separator must be installed in correspondence of the discharge line.

4.7. Overheating alarm (optional)

- The vacuum pump can be equipped at the request of thermostat sensor. (See Fig. 4.1).

- Overheating alarm is strongly recommended in the following cases:

- Operations close to the use limits.
- Under pressure operations.
- Not well defined or monitored operation conditions.

- The alarm (available upon request) is composed of a blinking light and a warning buzzer that have to be connected to the thermostat (sensor). It is available at 12V or 24V.


- Consider the thermostat characteristics (See Fig. 4.4).

- Voltage from 6V to 24V with CC, from 6V to 12V with AC.
- Maximum power: 3W.

- When threshold temperature is reached the alarm system is enabled and a gate valve (along vacuum line) is opened.

- It has to be mounted in a protected position in order to keep it free from water and other damaging media. Prepare the necessary connections for the electrical feeding.

- If the box supplied as an accessory is not used, make a check circuit as illustrated in Fig. 4.4.



Pic. 4.4

- Overheating can seize the vacuum pump, causing a damage also in the drive line. Stop the pump for cooling or drive it at free ports conditions (with the suction valves fully opened) to let it cool down properly. The pump can be again operated only when the alarm is turned off after cooling.

- Check the muffler cleanliness. Obstructions may cause overheating.



Attention: overheating can seize the vacuum pump, causing a damage also in the drive line.

4.8. Vacuum-pressure inverter: remote control actuators

- A specific design of the vacuum-pressure diverter available on request enables the application of a pneumatic or hydraulic angular actuator (90°).

- See the exploded view at the end of the manual for spare parts.

	Pneumatic actuator	Hydraulic actuator
Fluid	Filtered, dried compressed air	Hydraulic oil ISO-L-HM
Filtration	ISO 8573-1 classe 4 (15 micron)	ISO 4406 21/19/16
Temperature	°C -20 ÷ +80	-20 ÷ +80
Rated pressure	bar 5.6	150
Maximum pressure	bar 8.4	200
Supply holes	G 1/4	G 1/8

Hydraulic actuator installation


- Adjust movement speed using the two built-in valves.
- Use a closed-centre distributor or apply a block valve.

Pneumatic actuator installation

- Adjust movement speed by applying two unidirectional flow control valves.

For both actuators


- Adjust speed: full rotation should not take less than 1 second.
- Fluid filtration: ensure a level equal to or greater than the recommended value.
- In the event of a (hydraulic or pneumatic) supply failure, the suction unit inverter will remain in the same position it was when the failure occurred.




Pic. 4.5

Maintenance

- The diverter is adjusted before shipment and does not usually require further adjustments.
- Diverter lubrication:
 - Use Lithium grease NLGI 2. Quantity: 50 g every 1000 work cycles.
 - Do not grease using excessive amounts of grease.
- Hydraulic actuator: the control valves are equipped with an internal metal filter. Disassemble and clean if movement stops.
- Pneumatic actuator: for non-dried air, use temperature $0 \div +80^{\circ}\text{C}$.
- The following figure shows a possible schematic view of a correct hydraulic connection.



- The following figure shows a possible schematic view of a pneumatic connection.




- In case of interruption of the pneumatic or hydraulic supply, the inverter of the suction unit remains in the same position it was when the failure occurred.

4.9. Pump mounting - drive connection

- For the machines of this series, the allowed power transmissions are
 - Direct transmission (e.g.: from agricultural cardan shaft)
 - Oil hydraulic transmission (HDR)
- Protect with a fixed or interlocked guard and signal with pictograms the power transmission chosen and applied by the final installer, if there is the possibility that the operator will come into contact during handling.

A) Cardan shaft drive

- Use telescopic cardan shafts.
- In order to achieve a uniform motion of the driven shaft, the following requirements must be met (see Pic. 4.6):
 - Equal working angle α and α_1 of both couplings;
 - The internal fork joints must be coplanar;
 - Both driven and driving shafts must be coplanar.



Pic. 4.7

- It is also recommended working with limited articulated joint angles (max 15°) and disengaging the transmission for those operations requiring great angles (steering or lifting).



Follow the rotation direction as indicated on the pump front conveyor protection. Follow the instructions of the cardan shaft's manufacture.

- Use the cardan guard supplied with the pump, by fixing it to the pump itself.



Use the cardan guard supplied with the pump, by fixing it to the pump itself. In any case, the installation, by the final installer, must comply with the current EC accident prevention regulations and must be compatible with the geometry of the protection cap supplied with the machine.

- The protection must not be removed; in case of removal, it is the responsibility of the final installer to provide for suitable guards according to the assembly.

- It is the responsibility of the final installer to provide for suitable guards, in presence of transmission shafts exposed during normal operation.


B) Belt drive

- Install a suitable pulley on the smooth shaft as close as possible to the pump in order to avoid excessive bending stress on the drive shaft.
- Apply an adequate belt tension (see list below).

- Do not use driven or driving pulleys with a pitch diameter inferior to values reported in the box below. Small pulleys require a high belt tension which may cause premature wear to the bearing or transmission damages.

- A limited speed ratio will extend the belts life and reduce stress on the shafts. When possible prefer:

- Pulleys with a pitch diameter bigger than the one indicated;
- Engines or power take-offs with a speed similar to the one of the vacuum pump.



Pic. 4.8

Model	Max. Speed (rpm)	T. max (N)	L. max (mm)	Min. pitch diameter (mm)	Nr. Grooves	Belts type
PNR/PNE 73 -83	1350	2200	25	200	2	XPB
PNR/PNE 104-124	1300	3300	35	200	3	XPB
PNR 142	1300	3300	35	200	3	XPB

Pitch Diameter. min.: Minimum drive of pulley pitch diameter.

C) Hydraulic drive transmission (PNR/PNE HDR)


Model	Displacement	Operating pressure (max. vac.)	Operating pressure (1 rel. bar)	Flow	Max pressure draining line	Max. pressure motor exhaust	Max pressure
PNR/PNE73	44 cc/rev	140 bar	170 bar	62 l/min (1350rpm)	5 bar	5 bar	220 bar
PNR/PNE83	44 cc/rev	160 bar	210 bar	62 l/min (1350rpm)	5 bar	5 bar	220 bar
PNR/PNE104	61 cc/rev	130 bar	170 bar	83 l/min (1300rpm)	5 bar	5 bar	180 bar
PNR/PNE124	72 cc/rev	130 bar	170 bar	98 l/min (1300rpm)	5 bar	5 bar	220 bar
PNR 142	86 cc/rev	150 bar	200 bar	110 l/min (1200rpm)	5 bar	5 bar	220 bar

(*) : Oil temperature, used in the main circuit.

- **Fluid:** mineral oil for hydraulic systems in compliance with ISO/DIN.

Temperature	Optimum viscosity ale	Max. viscosity allowed
-20 / +80 °C	12 – 100 cSt	750 cSt

- **Filtration:** class 21/19/16 contamination according to ISO 4406 to be obtained with a $\beta_x = 75$ filter.



Pic. 4.9

- **Check circuit connections:** they must be applied in the same rotation direction as that indicated by the arrow on the pump front flange.

- **Draining:** connect directly to the tank above the maximum oil level. Operating without draining line may damage the motor.

- **Distributor:** open-centre distributor in central idle position (vacuum pump off). It must be equipped with an adjustable overpressure safety valve.

- **Motor pipeline:** outlet pipe must not be of a smaller diameter than that of the inlet port. Inlet pipes always have a diameter smaller than outlet pipes. Choose preferably flexible pipes to avoid vibration transmission.


- **Tank:** with suction pipe and return separated by baffles. If necessary, use a heat exchanger to avoid oil heating above 70-80°C and protect it from extreme pressure with a pressure relief valve. Minimum approximate capacity: as twice as the circulation flow.

• **Starting-up:** be sure that the system is well cleaned and pour oil into the tank and into the motor housing (necessary to lubricate the internal bearings).

• Vent the circuit and adjust the overpressure safety valve to the lowest possible value.

• Check the oil tank level.

• Increase pressure and rotation speed until operating values are reached.



Pic. 4.10

1	HYD Pump	4	Oil filter
2	Distributor	5 *	Heat exchanger
3	HYD Motor	6 *	Safety valve

* optional components

• The machine/system manufacturer is responsible for dimensioning the lines.



The machine/system manufacturer is responsible for dimensioning the lines.

5. Start up

5.1. Pump starting-up

- Before starting the equipment check the lubricating oil level of the pump by means of the proper dip stick.
- Refill the tank with lubrication oil.
- Check the oil level in the gear box (if the pump is provided with it).
- In order to choose the most suitable oil, see paragraph. 2.5.
- Check that all protection and safety devices are correctly installed.
- Check that no obstacles obstruct the vacuum and pressure line or the air injection cooling system.
- Check rotation direction: open all system valves and start running at slow speed.



Do not rotate in the wrong direction: pump may be damaged.

- Check which position of the 4-way integrated valve lever allows vacuum or pressure functioning.
- Close the valve and increase vacuum rate (or operating pressure).
- Check loading and operating speed for vibrations or unusual noises.



This vacuum pump is designed to work at maximum speed. For longer operating we recommend the pump be run at working speed.

- Prepare adequately transmission.

5.2. Operating precautions

- Run the vacuum pump at a room temperature of -20°C e +40°C.
- Do not make the vacuum pump overheat. Maximum air temperature on exhaust (or delivery) side: 160-180°C.
- Do not operate the pump without lubrication: it may cause quick wear and possible breakdown of vanes.
- Do not start running the pump under load: that causes stress to the drive system and the hydraulic motor.
- Check rotation speed. The vacuum pump must never exceed the maximum speed or run below the minimum speed.
- Do not accidentally operate the pump in the wrong direction: it may break the vanes.
- Do not convey the exceeding delivery outlet towards the suction port, otherwise it will suck warm gas.
- Control the air flow by adjusting the rotation speed: do not use the pressure relief valve to discharge the exceeding flow.
- Once that the wanted vacuum rated has been attained it is recommendable to decrease the speed, (see par. 2.3). This useful procedure, that will not increase the time requested to fill up the tank, will however result in a lesser wear of the vanes. It is suggested to reduce the speed also when operating with pressure.
- When, exhaust temperature is reduced, vane durability is increased and both oil consumption and power absorption are reduced.



Once the needed vacuum rate has been reached, we recommend reducing the vacuum pump speed to its working speed.

- After operation in dusty environments, after accidental sucking of liquids inside the pump or before a long inoperativity period it is recommended to wash the pump inside according to the following procedure:

1. Before washing the pump, be sure that it has cooled down. To obtain this in a short time, it is possible to run the pump for a few minutes at zero vacuum conditions, or stop it at all;



Attention: Do not carry out this operation on very hot pumps (for example after a working day) until they have cooled down.

2. Use 1-2 liters of water mixed with a non-flammable detergent. We suggest some product like Henkel Bonderite C-NE 5225: 5% concentration in water. This detergent grants a good protection against rust and oxidation.
3. Use one of the openings placed in the vacuum line (closet on the pump) to suck some water mixed with detergent.
4. Start the pump at low speed leaving opened all the suction valves in the tank, in order to keep low the vacuum rate (max vac. 10-20%). Let the detergent mix entering the pump very slowly.
5. The detergent mix stays suspended in the pump inside, before being expelled through the exhaust silencer.
6. After keeping the pump speed for a while to make the product reaching the internal parts, it is necessary to dry the pump preventing oxidation. When the detergent mix is finished, continue running the pump at the lowest possible vacuum rate for a few minutes, then close venting and suction valves up to 50-60% maximum, for a couple of minutes. With this operation the pump will dry from the heated air and protected from the chemical attack of the detergent.
7. Washing the pump with this detergent guarantees a protection after some days of inoperativity. If the pump is not used for more than two weeks, after having washed and dried the inner parts as described above, it is recommended to suck slowly 200 cc anti-rust and water-repellent protective oil (or, if not available, a very fluid gear oil).



Attention: do not carry out also this operation on very hot pumps (for example after a working day) until they have cooled down.



In case the exhaust line cannot be disconnected, drain the liquids accumulated in the separator of the exhaust silencer.

- Do not convey the exceeding flow outlet towards the suction port.
- Control the air flow by adjusting the rotation speed: do not use the safety relief valve to discharge the exceeding flow.
- Do not squeeze the hoses/pipes.
- If the decompressor operates in vacuum or under pressure with a capacity environment (such as a cistern) and is configured in the "FL"

flanged version (without manifold with 4-way valve and non-return valve), it is advisable to intercept the working line of the machine when it is stopped, to prevent contrary rotations until the rebalancing of the pressures. The interception can take place through a controlled valve or an automatic unidirectional valve (swing valve).

- Avoid starting the pump under load: motor and drive system can be excessively stressed.

- With temperature below 5 °C (40 °F) and long periods of inactivity, introduce some quantity of oil through the suction connection before starting off the pump.

- The air injection cooling system grants the use of the vacuum pump at high vacuum rates. Anyway it has to be remembered that the pump has been designed for non-continuous work. This cooling system allows to dissipate part of the accumulated heat still at satisfactory lubrication conditions. Continuous, heavy-duty work, or prolonged work periods will cause an over-heating of the pump, consequently reducing performances and durability.

- With the PNR models it is quite normal that the vacuum rate in the tank will fall down at about 50%, if and when the pump is stopped for sufficient time. This because atmospheric air will flow back in the tank through the injection valves, which are adjusted at approximately 0,5 bar. Vent the tank and take it to atmospheric pressure when stopping the pump in order to avoid back rotation of the pump.

6. Maintenance

6.1. Ordinary maintenance

- Any interventions must be performed when the machine is cold, stopped and switched off.
- Installation and maintenance must be operated only by qualified personnel wearing the proper clothes and the necessary tools as well as protection devices.
- Use suitable protection equipment (gloves, protection glasses, boots...)
- In the following table summarizes the main controls to be performed and the frequency of intervention.


Operating Condition	Maintenance Area	Check	8H	50H	500H	1000H
OPERATING	Vacuum line	Check safety valve (non-return valve)				
		Operating pressure				
	Transmission / Pump	Lubrication: dripping into oilers (PNR/E 73-83 e PNR 142)				
		Rotation speed				
		Sound pressure level (also HDR motor)				
STANDSTILL	Vacuum line	Suctions filters				
		4-way changeover valve: check and lubricate				
	Pump	Clean oilers glasses (PNR/E 73-83 e PNR 142)				
		Check oil level				
		Check vanes wear				
		Change oil (*)				
		Pump's inner washing (**)				
	Overall	Greasing				
		Check cardan shaft drive				
		Check transmission pulley				
		Swing valve wear check				

(*) The first oil change must be done inside 500 hours operation. Following changes every 5000 hours or 12 months. In order to choose the most suitable oil, see paragraph 2.5.

(**) After operation in dusty environments, after accidental sucking of liquids inside the pump or before a long inoperativity period it is recommended to wash the pump inside according to the procedure described at paragraph 5.2.

Checking the oil tank level

- Before starting the machine, check the lubricating oil level.



Pic. 6.1

- Do not run the pump with oil level under the minimum level: that may lead to dry functioning and cause serious damages. (Pic. 6.1).
- Rear mounted tank capacity: **3,2 l.**
- Side mounted tank capacity: **4 l.**

- See paragraph 2.3 for the oil consumption of each model.
- Top up with fresh and clean oil only; use the oil required in paragraph 2.6 or equivalent.
- The oil must be topped-up with the machine stopped and cold.




Do not reuse the oil collected by the separator applied to the pump drain.

- Apply the safety requirements indicated in chapter "Safety and accident prevention" before topping-up.

Checking the gearbox oil level

- The oil must be topped-up with the machine stopped and cold.
- Apply the safety requirements indicated in chapter "Safety and accident prevention" before topping-up.
- The oil level in the gearbox must reach the side discharge hole.



- For the replacement, drain the oil from the gearbox through the lower discharge plug and top-up through the upper filling plug until it comes out of the side discharge hole.

- See the table in paragraph 6.1 for the frequency with which to replace the oil.



Dispose of exhausted oil as provided by current specification.

- Top up with fresh and clean oil only; use the oil required in paragraph 2.6 or equivalent.
- During the oil replacement, also replace the discharge plug washer.

Lubrication control (PNR-PNE73-83 e PNR142)

- Check that the lubricant drips properly into the oilers: 60 droplets/min at maximum speed. For lower speeds: the number of droplets is directly proportional.
- Keep the glass of the oilers clean and in an accessible position.



If lubrication is missing, the decompressor heats up and the internal components quickly deteriorate. Stop the decompressor, check the oil level and the lubrication pump.

- Temporary build-up of lubricant in the oilers is possible:
 - During pressurised service even with regular dripping,
 - With the decompressor stopped.
- This phenomenon:
 - Is transient: the oilers empty during the subsequent vacuum operation.
 - This does not indicate faults and does not jeopardise lubrication of the internal parts during pressurised operation.




Once pump is stopped, oilers may be filled up with oil. This does not mean any pump failure because oilers will get empty on next pump-vacuum mode start.

- During vacuum operation, the build-up of oil in the oilers could indicate insufficient lubrication. Check:
 - Piping: it could be obstructed or crushed.
 - Fittings: they could be loosened.

Checking the vanes wear


- Unscrew the vanes wear check-plug on the front flange. See Pic. 6.2.



Pic. 6.2

- Turn the shaft by hand until vanes appearance.
- Vanes usually slip on seat bottom due to gravity. Check their right entry in the seat.

- Insert a $\varnothing 6$ mm stick until it touches the rotor and then mark like in Pic. 6.3.
- Turn the rotor slowly until the stick touches the vane in idle position in its seat. The vanes slide to the bottom of the seat due to gravity: check they really do and mark again on the stick.
- Repeat the same procedure for all the vanes. If wear exceeds 10 mm: replace the vanes as soon as possible.



Pic. 6.3

- Replace all the pump vanes at the same time.



Replace the vanes when their wear exceeds 10 mm (L – L min): they may break. Replace all vanes at the same time.

- Replace the vanes when their wear exceeds 10 mm (L – L min): they may break. Replace all vanes at the same time.

6.2. Extraordinary maintenance


- Except for the cases described below, extraordinary maintenance on a PNR/E must be carried out by specialized personnel only; otherwise the guarantee will be invalidated.
- All extraordinary maintenance interventions must be carried out when the machine is cold, stopped and switched off. Implement the safety instructions reported in the "Safety and accident prevention" Chapter, before performing any maintenance operation.



Follow the safety prescriptions as described in Cap. "Safety and accident prevention".

Replacing the vanes (PNR/PNE 73-83-104-124)

- Remove the vacuum pump from its bearing frame and wash it before disassembling.
- It is suggested to remove the oil tank on the rear part because generally the pump's drive components are fitted on the front flange. Use always the specific kit of gaskets for the pump model at hand (see also spare parts list).
- Material that is subject to wear: replace.




Pic. 6.4

Pos.	Code	Description
1	1684000000	PLUG 3/8
2	1640101200	TANK'S CAP
3	1680707700	CAP'S GASKET
4	4026706101	PIPE'S FITTING
5	4024251000	OIL PUMP (RIGHT)
	4024251500	OIL PUMP (LEFT)
6	4022200111	SEAL 72X48X15
7	16125006E0	OIL TANK
8	4022200309	OR
9	1610508500	PUMP'S FLANGE
10	4026300020	COMPENSATION RING
11	4023100040	BEARING

Disassemble operation

- Drain the oil tank through the proper port (pos. 1).
- Remove the tank's cap (pos. 2) and change the gasket (pos. 3); unscrew the lubrication pipe's fittings (pos. 4) connecting the oil pump to the oilers.
- Remove the oil pump (pos. 5).
- Remove the screws fixing the oil tank (pos. 7) and carefully remove it, eventually using two screws partially winded inside the threads. Avoid that the rotor falls down inside the housing, supporting it if necessary with adequate tools.
- Change the OR (pos. 8).
- Remove the oil pump's flange (pos. 9), the compensation ring (pos. 10) and the bearing (pos. 11) this will make the reassembly of the oil tank much easier (pos. 7).
- Lubricate the new vanes before inserting them in the rotor's slots.
- The new vanes have to be inserted with the rounded corner facing towards the housing (See Pic. 6.5).




Pic. 6.5

Assemble operation

- Reassemble everything again in the right sequence, absolutely avoiding to leave foreign parts inside the pump. Always change all the gaskets and the OR after having them properly lubricated and also the seal (pos. 6) if necessary. Put some grease in the space between the bearing (pos. 11) and the flange (pos. 9).
- Reassemble the oil tank (pos. 7) and the OR (pos. 8) carefully inserting the drive shaft without damaging the seal.
- Insert the bearing (pos. 11), the compensation ring (pos. 10), and the oil pump's flange (pos. 9).
- Insert correctly the lubrication pump in the driving slot and refit the flange.
- Reassemble the lubrication pipes and fittings.
- Reassemble the tank's cap (pos. 2) and the gasket (pos. 3).
- Replace the plug on the tank (pos. 1) and refill it with lubrication oil.

Replacing the vanes (PNR 142)



Pic. 6.6

Pos.	Code	Description
1	1610508100	FLANGE
2	1610512900	PUM'S FLANGE
3	1642100200	REAR PROTECTION
4	4022200113	SEAL 70X55X15
5	4022200311	OR
6	4023100150	BEARING
7	4024251000	OIL PUMP (RIGHT)
	4024251500	OIL PUMP (LEFT)
8	4026300025	COMPENSATION RING
9	4026706101	PIPE'S FITTING

- Remove the vacuum pump from its bearing frame and wash it before disassembling.
- It is suggested to remove the oil tank on the rear part because generally the pump's drive components are fitted on the front flange. Use always the specific kit of gaskets for the pump model at hand (see also spare parts list)
- Material that is subject to wear: replace.

Disassemble operation

- Remove the rear protection (pos. 3).
- Unscrew the lubrication pipe's fittings connecting the oil pump (pos. 9) to the oilers.
- Remove the oil pump (pos. 7).
- Remove the screws fixing the flange (pos. 1) and carefully remove it, eventually using two screws partially winded inside the threads. Avoid that the rotor falls down inside the housing, supporting it if necessary with adequate tools.
- Change the OR (pos. 5).
- Remove the oil pump's flange (pos. 2), the compensation ring (pos. 8) and the bearing (pos. 6) this will make the reassembly of the oil tank much easier.
- Lubricate the new vanes before inserting them in the rotor's slots.
- The new vanes have to be inserted with the rounded corner facing towards the housing (See Pic. 6.5).

Assemble operation

- Reassemble everything again in the right sequence, absolutely avoiding to leave foreign parts inside the pump. Always change all the gaskets and the OR (pos. 5) after having them properly lubricated and also the seal (pos. 4) if necessary. Put some grease in the space between the bearing (pos. 6) and the flange (pos. 1).
- Reassemble the flange (pos. 1), and the OR (pos. 5) carefully inserting the drive shaft without damaging the seal (pos. 4).
- Insert the bearing (pos. 6), the compensation ring (pos. 8) and the oil pump's flange (pos. 2).
- Insert correctly the lubrication pump (pos. 7) in the driving slot and refit the flange.
- Reassemble the lubrication pipes and fittings.
- Reassemble the rear protection (pos. 3).

General warnings

- On direct drive models normally it is not necessary to remove the front small flange. However, if this has to be done do not forget to grease the underneath bearing.
- The front bearing has been greased during pump's assembling. Lubrication of said bearing is necessary after long working periods only (for example, normal duration of a set of vanes). It is consequently suggested to pump carefully new grease through the lubrication nipple in order to avoid damages to the seals.
- When changing the vanes do not forget to carefully clean all the components that you have dismantled. Clean the oil filter and the oil tank from the solid sediments. The models PNR142, are provided with a side oil tank; be careful to the maximum tight torque of the oil filter plug. Maximum torque: 10Nm.

Mounting the hydraulic drive

- We recommend the drive coupling be oiled when vanes are being replaced.
- However lubricate the drive coupling every 1500 hours.




We recommend the drive coupling be oiled every 1500 hours.

- Apply coupling hub to vacuum pump axis respecting the position marked during disassembly: the grain must go back into the seat on the rim.
- Mount the coupling and lubricate internally with NLGI 2 Lithium grease. Provide an adequate quantity of fat, in order to have a medium filling.
- Reassembly the motor without forcing onto the seals.

Adjusting the self-lubricating pump

- The automatic lubricating pump is adjusted by the manufacturer before the shipping.
- If consumption noticeably differs from the indicated value, adjust it as follows:
 - Remove the upper protection cover;
 - Using a screwdriver and a 10 mm wrench, adjust the adjusting screw (K). Close the nut and remount the upper protection cover;
 - It is advisable to turn the screw of $\frac{1}{4}$ of turn and verify the actual consumption.



Pic. 6.7



Do not reduce oil consumption below the value indicated in par. 2.2 (for functioning at speeds different from the maximum, flow is proportionate to rotating speed).

- $\frac{1}{2}$ turn of the adjusting screw causes a variation in the flow of approximately 40 - 80 g/h, depending on using conditions.

Cleaning of the inside exhaust port of the pump housing and the 4-way manifolds

- Frequency: at every changing of the vanes.
- How to proceed: dismantle the manifold and remove possible oilscales or other foreign parts.
- The clogging-up of this manifold and the exhaust port depends mainly from heavy duty use of the pump and causes an increase of temperature and a non-perfect closing of the check valve. A careful cleaning of all components, including the insides of the housing and the non-return check valve and its seat, is therefore strongly recommended.

7. Malfunctions: troubleshooting

PROBLEMS

Overheating

Cause	Solution
• Faulty lubrication	• Check the oil pump
• Missing oil	• Fill up the oil tank
• Revolutions too high	• Reduce the speed
• Operating time too long at too high vacuum rate	• Decrease the vacuum rate
• Clogged filters on the air injection system	• Clean the filters
• Insufficient diameter of vacuum and discharge line	• Check the correct dimensions of the line (minimum suggested 3")

The pump is blocked

Cause	Solution
• Broken vanes:	• Dismantle the pump and change the vanes
- due to foreign parts	• Check/clean the filters and elements on the vacuum line
- due to faulty lubrication	• Check the lubrication pump
• Damaged drive system	• Change the damaged parts
• Frozen up pump	• Warm-up the pump

Reduced performances

Cause	Solution
• 4-way valve handle in neutral position	• Move the handle against the resting pin
• Worn vanes	• Change the vanes
• Leaking check valve	• Clean the check valve
• Worn O-rings	• Change the seals
• Leaking gaskets and/or valves on the vacuum tank	• Change that damaged parts
• Clogged connecting pipeline	• Change the damaged hoses - pipes
• Floating ball or air filter obstructed	• Dismantle and clean
• Crusted up exhaust manifold	• Dismantle and clean
• Vacuum line components under-dimensioned	• Check the dimensioning for the pump model at hand
• Rubber connection obstructed or damaged	• Change the connections

Abnormal oil consumption

Cause	Rimedi
• Insufficient lubrication	• Adjust the oil pump flow
• Excessive oil consumption	• Loss of adjustment of the oil pump • Probable wear or breakage of the seal rings of the vacuum pump shaft. Replace them • Check the fittings built on the automatic oil pump and screw tight

8. Scrapping

• Recycling materials allow reducing the environmental impact and respecting the environment.

• Before scrapping the machine, the following materials need to be separated and suitably disposed of.





Do not dispose of in the environment. Dispose of in compliance with the standards in force.



Material	Cast Iron	Steel	Aluminum	Copper	Bronze	Rubber	Vane	Oil	Plastic
PNR-PNE 73	83 %	14 %	1 %	0,1 %	0,1 %	0,1 %	1 %	0,4 %	0,3 %
PNR-PNE 83	84 %	13 %	1 %	0,1 %	0,1 %	0,1 %	1 %	0,4 %	0,3 %
PNR-PNE 104	87 %	10 %	0,7 %	0,3 %	0,1 %	0,1 %	0,6 %	0,6 %	0,2 %
PNR-PNE 124	88 %	10 %	0,6 %	0,3 %	0,1 %	0,1 %	0,7 %	0,5 %	0,2 %
PNR 142	91 %	7 %	0,5 %	0,2 %	0,1 %	-	0,5 %	0,5 %	0,2 %

9. Accessories

Silencers / Oil separators




MODEL	PNR-PNE 73-83
TYPE	DISCHARGE
CODE	15470 043 00
MAX FLOW	540 m³/h
OIL TRAP	3,8 l
WEIGHT	27 kg



MODEL	PNR-PNE 104-124 – PNR 142
TYPE	DISCHARGE
CODE	15470 D2C B0
MAX FLOW	912 m³/h
OIL TRAP	4,4 l
WEIGHT	35 kg

Note: Direct the silencer discharge output away from the silencer suction inlet in order to prevent the input of hot fluids into the injection inlet.

PNR/PNE 73-83 D




PICTURE SHOWS
PNR 73 D SMOOTH SHAFT
COD. A730809440

PNR/PNE 73-83 D

Pos.	Code	Description	Q.ty	Pos.	Code	Description	Q.ty
1	1401200700	OIL DRIPPER AUTOMATIC LUBRICATION	2	43	1684000000	DRAIN PLUG 3/8	4
2	14933006E0	AIR INJECTION VALVE 1/2"	2	44	1685002800	WASHER FE 30X8,5 SP.4 ZIN.	1
3	1601605700	VANE PNR 73	5	45	1685100000	OIL DRIPPER WASHER 14X20X1.5	2
	1601605800	VANE PNR 83	5	46	1685100200	WASHER ALU. 17X22X1,5	4
	1601605300	VANE PNE 73	5	47	1685100800	WASHER COP. 8X14X1,5	2
	1601605400	VANE PNE 83	5	48	16875037E0	PUMP HOUSING PNR-PNE 73	1
4	1605500000	HANDLE	1		16875038E0	PUMP HOUSING PNR-PNE 83	1
5	16081002E0	DISTRIBUTOR	1	49	1691000000	CONVEYOR SPRING	1
6	1608501700	CONVEYOR	1	50	18930009E0	CLAPET VALVE	1
7	1610500400	FLANGE	1	51	4022200030	SEAL 41X27X10	1
8	16105013E0	FLANGE	1	52	4022200040	SEAL 72X40X10	1
9	1610508500	AUTOMATIC LUBRICATION PUMP FLANGE	1	53	4022200111	SEAL 72X48X15	2
10	16120276H0	AIR INJECTION PIPE BRACKET	1	54	4022200308	O-RING 4775	2
11	16120816F0	DISTRIBUTOR BRACKET	1	55	4022300001	NYLON FILTER	1
12	16125012E0	OIL TANK	1	56	4022301001	SILENCER-FILTER ¼	1
13	1621503300	ROTOR PNR/PNE 73	1	57	4022301004	SILENCER-FILTER ¾	2
	1621503400	ROTOR PNR/PNE 83	1	58	4023100040	BEARING 6308	2
14	1622002600	SHAFT	1	59	4024251000	AUTOM. LUBRICATION PUMP CW ROTATION	1
15	1623100000	CONVEYOR CAP	1		4024251500	AUTOM. LUBRICATION PUMP CCW ROTATION	1
16	1624007500	BUSHING 40X48X22	2	60	4026102702	SCREW TE M 6X12 GALV.	2
17	162409YKB0	SPACER	1	61	4026102802	SCREW TE M 8X12 GALV.	3
18	1624202300	SPACER	1	62	4026102807	SCREW TE M 8X25 GALV.	27
19	1626001300	BUSHING	1	63	4026121305	SCREW TCEI M 6X16 GALV.	2
20	16275008E0	MANIFOLD	1	64	4026121401	SCREW TCEI M 8X12 GALV.	2
21	1640101100	OIL TANK CAP	1	65	4026121407	SCREW TCEI M 8X25 GALV.	16
22	16401098E0	CLAPET CAP	1	66	4026135414	SCREW M 8X45 GALV.	1
23	1642600000	PIPELINE PROTECTION	2	67	4026135504	SCREW 10X10 GALV.	1
24	1650014200	FRONT SMOOTH SHAFT	1	68	4026300020	COMPENSATION RING	2
	1650014100	FRONT SPLINED SHAFT	1	69	4026308005	NUT M 8 ESAG. GALV.	2
25	1650014300	REAR SHAFT	1	70	4026350505	WASHER GROWER 8 GALV.	16
26	1663014000	AIR INJECTION PIPE	2	71	4026351504	WASHER M 6 GALV.	2
27	1663041200	SUCTION LINE FOR AUT. LUBR. PUMP	1	72	4026351505	WASHER M 8 GALV.	27
28	16630422E0	LUBRICATINGLINE PNR-E 73 D CW/CCW	1	73	4026356002	WASHER 8X24	3
	16630428E0	LUBRICATINGLINE PNR-E 83 D CW/CCW	1	74	4026359006	WASHER 13,5X18X1,5	2
29	16630431E0	FRONT LUBRICATINGLINE PNR-E 73 D CCW	1	75	4026500909	TAB 10X8X50	1
	16630421E0	FRONT LUBRICATINGLINE PNR-E 73 D CW	1	76	4026701301	FITTING	2
	16630434E0	FRONT LUBRICATINGLINE PNR-E 83 D CCW	1	77	4026702004	FITTING 6X1/8	4
	16630427E0	FRONT LUBRICATINGLINE PNR-E 83 D CW	1	78	4026706000	FITTING 90° 4X1/8	2
30	16630426E0	REAR LUBRICATINGLINE PNR-E 73-83 D CCW	1	79	4026706003	FITTING 90° 6X1/8	2
	16630425E0	REAR LUBRICATINGLINE PNR-E 73-83 D CW	1	80	4026706101	FITTING	2
31	16630432E0	FRONT OIL DRIPPER LINE PNR-E 73 D CCW	1	81	4026706104	FITTING	1
	16630423E0	FRONT OIL DRIPPER LINE PNR-E 73 D CW	1	82	4026740011	REDUCED NIPPLE G1/4	1
	16630435E0	FRONT OIL DRIPPER LINE PNR-E 83 D CCW	1	83	4026910601	PLUG 1/8"	2
	16630429E0	FRONT OIL DRIPPER LINE PNR-E 83 D CW	1	84	4027409920	ONE-WAY VALVE G1/4	1
32	16630433E0	REAR OIL DRIPPER LINE PNR-E 73 D CCW	1	85	4029602806	DRIVE SHAFT PROTECTION	1
	16630424E0	REAR OIL DRIPPER LINE PNR-E 73 D CW	1		18920102E0	GASKETS KIT	1
	16630436E0	REAR OIL DRIPPER LINE PNR-E 83 D CCW	1				
	16630430E0	REAR OIL DRIPPER LINE PNR-E 83 D CW	1				
33	1672001600	SCREW TCEI M10X1,5	10				
34	1680609700	OIL PUMP GASKET	1				
35	1680609800	OIL PUMP FLANGE GASKET	1				
36	1680700200	CONVEYOR GASKET	1				
37	1680700400	FLANGE GASKET	1				
38	16807020E0	CLAPET GASKET	1				
39	16807021E0	MANIFOLD DISCHARGE GASKET	1				
40	16807022E0	MANIFOLD SUCTION GASKET	1				
41	1680707500	OIL TANK CAP GASKET	1				
42	1683600000	OIL STICK 160MM	1				

PNR/PNE 73-83 M




COD. A733209440

PICTURE SHOWS
PNR 73 WITH MULTIPLIER

PNR/PNE 73-83 M

Pos.	Code	Description	Q.ty	Pos.	Code	Description	Q.ty
1	1401200700	OIL DRIPPER AUTOMATIC LUBRICATION	2	47	1685100800	WASHER RAME 8X14X1,5	2
2	14933006E0	AIR INJECTION VALVE 1/2"	2	48	16875037E0	PUMP HOUSING PNR-PNE 73	1
3	1601605700	VANE PNR 73	5		16875038E0	PUMP HOUSING PNR-PNE 83	1
	1601605800	VANE PNR 83	5	49	1691000000	CONVEYOR SPRING	1
	1601605300	VANE PNE 73	5	50	18930009E0	CLAPET	1
	1601605400	VANE PNE 83	5	51	4022200030	SEAL 41X27X10	1
4	1605500000	HANDLE	1	52	4022200040	SEAL 72X40X10	1
5	16081002E0	DISTRIBUTOR	1	53	4022200111	SEAL 72X48X15	2
6	1608501700	CONVEYOR	1	54	4022200308	O-RING 4775	2
7	1610508300	FLANGE	1	55	4022300001	NYLON FILTER	1
8	1610508500	AUTOMATIC LUBRICATION PUMP FLANGE	1	56	4022301001	SILENCER-FILTER ¼	1
9	16120276H0	AIR INJECTION PIPES BRACKET	1	57	4022301004	SILENCER-FILTER ¾	2
10	16120816F0	DISTRIBUTOR BRACKET	1	58	4023100018	BEARING 6206	1
11	16125012E0	OIL TANK	1	59	4023100040	BEARING 6308	3
12	1612503200	GEARBOX	1	60	4024251000	AUTOM. LUBRICATION PUMP CW ROTATION	1
13	1621503300	ROTOR PNR/PNE 73	1		4024251500	AUTOM. LUBRICATION PUMP CCW ROTATION	1
	1621503400	ROTOR PNR/PNE 83	1	61	4026102702	SCREW TE M 6X12 GALV.	2
14	1622002600	SHAFT	1	62	4026102802	SCREW TE M 8X12 GALV.	3
15	1623100000	CONVEYOR CAP	1	63	4026102807	SCREW TE M 8X25 GALV.	24
16	1624007500	BUSHING 40X48X22	2	64	4026102808	SCREW TE M 8X30 GALV.	7
17	162409YKB0	SPACER	1	65	4026121305	SCREW TCEI M 6X16 GALV.	2
18	1624202300	SPACER	1	66	4026121401	SCREW TCEI M 8X12 GALV.	2
19	16275008E0	MANIFOLD	1	67	4026121407	SCREW TCEI M 8X25 GALV.	16
20	1640101100	OIL TANK CAP	1	68	4026135414	SCREW M 8X45 GALV.	1
21	16401098E0	CLAPET CAP	1	69	4026135504	SCREW M 10X10 GALV.	1
22	1642600000	PIPLINE PROTECTION	2	70	4026300020	COMPENSATION RING	2
23	1650014000	FRONT SHAFT	1	71	4026305616	NUT M30X2 ESAG. AUTOBL.	1
24	1650014300	REAR SHAFT	1	72	4026308005	NUT M 8 ESAG. GALV.	2
25	1651005400	PINION Z24	1	73	4026350505	WASHER GROWER 8 GALV.	16
26	1651005600	GEAR Z60	1	74	4026351504	WASHER M 6 GALV.	2
27	1663014000	AIR INJECTION PIPE	2	75	4026351505	WASHER M 8 GALV.	31
28	1663041200	SUCTION LINE FOR AUT. LUB. PUMP	1	76	4026356002	WASHER 8X24	3
29	16630425E0	FRONT LUBRICATINGLINE PNR-E M CW	1	77	4026359006	WASHER 13,5X18X1,5	2
	16630426E0	FRONT LUBRICATINGLINE PNR-E M CCW	1	78	4026500905	TAB 10X8X32	1
30	16630426E0	REAR LUBRICATINGLINE PNR-E M CW	1	79	4026701301	FITTING	2
	16630425E0	REAR LUBRICATINGLINE PNR-E M CCW	1	80	4026702004	FITTING 6X1/8	2
31	16630432E0	FRONT OIL DRIPPER LINE PNR-E 73 M CW	1	81	4026706000	FITTING 90° 4X1/8	2
	16630423E0	FRONT OIL DRIPPER LINE PNR-E 73 M CCW	1	82	4026706003	FITTING 90° 6X1/8	3
	16630435E0	FRONT OIL DRIPPER LINE PNR-E 83 M CW	1	83	4026706101	ADJUSTABLE FITTING	2
	16630429E0	FRONT OIL DRIPPER LINE PNR-E 83 M CCW	1	84	4026740011	REDUCED NIPPLE G1/4	1
32	16630433E0	REAR OIL DRIPPER LINE PNR-E 73 M CW	1	85	4026910601	PLUG 1/8"	2
	16630424E0	REAR OIL DRIPPER LINE PNR-E 73 M CCW	1	86	4027409920	ONE-WAY VALVE G1/4	1
	16630436E0	REAR OIL DRIPPER LINE PNR-E 83 M CW	1	87	4029602806	DRIVE SHAFT PROTECTION	1
	16630430E0	REAR OIL DRIPPER LINE PNR-E 83 M CCW	1				
33	1672001600	SCREW TCEI M10X1,5	10		18920102E0	GASKETS KIT	1
34	1680609700	OIL PUMP GASKET	1				
35	1680609800	OIL PUMP FLANGE GASKET	1				
36	1680700200	CONVEYOR GASKET	1				
37	16807020E0	CLAPET CAP GASKET	1				
38	16807021E0	DISCHARGE GASKET	1				
39	16807022E0	SUCTION GASKET	1				
40	1680707400	GEARBOX GASKET	1				
41	1680707500	OIL TANK CAP GASKET	1				
42	1683600000	OIL STICK 160MM	1				
43	1684000000	DRAIN PLUG 3/8	7				
44	1685002800	WASHER FE 30X8,5 SP.4 ZIN.	1				
45	1685100000	OIL DRIPPER WASHER 14X20X1,5	2				
46	1685100200	ALU WASHER 17X22X1,5	7				

PNR/PNE 104-124 D




COD. A690809440

PICTURE SHOWS
PNR 104 D SMOOTH SHAFT

PNR/PNE 104-124 D

Pos.	Code	Description	Q.ty	Pos.	Code	Description	Q.ty
1	14933006E0	AIR INJECTION VALVE 1/2"	2	39	1680707700	OIL TANK GASKET	1
2	1601605900	VANE PNR 104	5	40	1680707800	CONVEYOR GASKET	1
	1601606000	VANE PNR 124	5	41	1683600300	OIL STICK	1
	1601605500	VANE PNE 104	5	42	1684000000	DRAIN PLUG 3/8	4
	1601605600	VANE PNE 124	5	43	1685002800	WASHER FE 30X8,5 SP.4 ZIN.	1
3	1605500100	HANDLE	1	44	1685100200	ALU. WASHER 17X22X1,5	4
4	16081001E0	DISTRIBUTOR	1	45	1685100800	COP. WASHER 8X14X1,5	2
5	1608502500	CONVEYOR	1	46	16875020E0	HOUSING PUMP PNR-PNE 104	1
6	16105005E0	FLANGE	1		16875019E0	HOUSING PUMP PNR-PNE 124	1
7	1610508200	FLANGE	1	47	1691000000	CONVEYOR SPRING	1
8	1610508500	AUTOMATIC LUBRICATION PUMP FLANGE	1	48	18930008E0	CLAPET	1
9	16120820E0	AIR INJECTION PIPES BRACKET	2	49	4022200030	SEAL 41X27X10	1
10	16120854E0	DISTRIBUTOR BRACKET	1	50	4022200044	SEAL 65X45X8	1
11	16125006E0	OIL TANK	1	51	4022200111	SEAL 72X48X15	1
12	1621503500	ROTOR PNR/PNE 104	1	52	4022200113	SEAL 70X55X15	1
	1621503600	ROTOR PNR/PNE 124	1	53	4022200309	O-RING 4875 VITON	2
13	1622002600	SHAFT M10	1	54	4022300001	NYLON FILTER	1
14	1623100500	CONVEYOR	1	55	4022301001	SILENCER-FILTER ¼	1
15	1624007500	BUSHING 40X48X22	1	56	4022301004	SILENCER-FILTER ¾	2
16	162409YKB0	SPACER	1	57	4023100040	BEARING 6308	1
17	1624202300	SPACER	1	58	4023100046	BEARING 6309	1
18	1626001100	BUSHING	1	59	4023130035	BUSHING 55X45X22	1
19	16275006E0	MANIFOLD	1	60	4024251000	AUTOM. LUBRICATION PUMP CW ROTATION	1
20	16401008E0	CLAPET CAP	1		4024251500	AUTOM. LUBRICATION PUMP CCW ROTATION	1
21	1640101200	OIL TANK CAP	1	61	4026102702	SCREW TE M 6X12 GALV.	5
22	1642600000	PIPLINE PROTECTION	2	62	4026102704	SCREW TE M 6 X 16 GALV.	4
23	1650014700	FRONT SMOOTH SHAFT	1	63	4026102807	SCREW TE M 8 X 25 GALV.	27
	1650014600	FRONT SPLINED SHAFT	1	64	4026121305	SCREW TCEI M 6 X 16 GALV.	2
24	1650014800	REAR SHAFT	1	65	4026121401	SCREW TCEI M 8 X 12 GALV.	2
25	1663014000	AIR INJECTION PIPE	2	66	4026121407	SCREW TCEI M 8 X 25 GALV.	16
26	1663041100	SUCTION LINE FOR AUTOM. LUBR. PUMP	1	67	4026135414	SCREW M 8X45 GALV.	1
27	16631030E0	LUBRICATINGLINE PNR-E 104 D CCW	1	68	4026135504	SCREW M 10 X 10 GALV.	1
	16631033E0	LUBRICATINGLINE PNR-E 104 D CW	1	69	4026300020	COMPENSATION RING	1
	16631037E0	LUBRICATINGLINE PNR-E 124 D CCW	1	70	4026300025	COMPENSATION RING	1
	16631035E0	LUBRICATINGLINE PNR-E 124 D CW	1	71	4026308005	NUT M 8 ESAG. GALV.	2
28	16631031E0	FRONT LUBRICATINGLINE PNR-E 104 D CCW	1	72	4026350505	WASHER GROWER 8 GALV.	16
	16631032E0	FRONT LUBRICATINGLINE PNR-E 104 D CW	1	73	4026351504	WASHER M 6 GALV.	2
	16631036E0	FRONT LUBRICATINGLINE PNR-E 124 D CCW	1	74	4026351505	WASHER M 8 GALV.	27
	16631034E0	FRONT LUBRICATINGLINE PNR-E 124 D CW	1	75	4026356001	WASHER 6X18 GALV.	3
29	16631024E0	REAR LUBRICATINGLINE PNR-E 104 D CCW	1	76	4026357003	WASHER M6 GALV.	4
	16631025E0	REAR LUBRICATINGLINE PNR-E 104 D CW	1	77	4026359006	WASHER 13,5X18X1,5	2
	16631020E0	REAR LUBRICATINGLINE PNR-E 124 D CCW	1	78	4026501006	TAB 12X8X56	1
	16631021E0	REAR LUBRICATINGLINE PNR-E 124 D CW	1	79	4026701301	FITTING	2
30	16631028E0	FRONT OIL DRIPPER LINE PNR-E 104 D CCW	1	80	4026702004	FITTING	4
	16631022E0	FRONT OIL DRIPPER LINE PNR-E 104 D CW	1	81	4026702708	COPPER WASHER 1"½	1
	16631026E0	FRONT OIL DRIPPER LINE PNR-E 124 D CCW	1	82	4026706000	FITTING 90° 4X1/8	2
	16631018E0	FRONT OIL DRIPPER LINE PNR-E 124 D CW	1	83	4026706003	FITTING 90° 6X1/8	2
31	16631029E0	REAR OIL DRIPPER LINE PNR-E 104 D CCW	1	84	4026706101	ADJUSTABLE FITTING	2
	16631023E0	REAR OIL DRIPPER LINE PNR-E 104 D CW	1	85	4026706104	ADJUSTABLE FITTING	1
	16631027E0	REAR OIL DRIPPER LINE PNR-E 124 D CCW	1	86	4026740011	REUCED NIPPLE G1/4	1
	16631019E0	REAR OIL DRIPPER LINE PNR-E 124 D CW	1	87	4026904005	PLUG 1"½	1
32	1672001600	SCREW TCEI M10X1,5	10	88	4027409920	ONE-WAY VALVE G1/4	1
33	1680609700	OIL PUMP GASKET	1	89	4029602806	DRIVE SHAFT PROTECTION	1
34	1680609800	OIL PUMP FLANGE GASKET	1				
35	16807009E0	SUCTION GASKET	1		18920026E0	GASKETS KIT	1
36	16807010E0	DISCHARGE GASKET	1				
37	16807011E0	CLAPET CAP GASKET	1				
38	1680707300	FRONT FLANGE GASKET	1				

PNR/PNE 104-124 CON MOLTIPLICATORE



PNR-PNE MOLT. 1000

PICTURE SHOWS:
PNR 104 WITH MULTIPLIER
COD. A693209440


PNR/PNE 104-124 M

Pos.	Code	Description	Q.ty	Pos.	Code	Description	Q.ty
1	14933006E0	AIR INJECTION VALVE 1/2"	2	44	1685100200	WASHER 17X22X1,5	7
2	1601605900	VANE PNR 104	5	45	1685100800	WASHER 8X14X1,5	4
	1601606000	VANE PNR 124	5	46	16875020E0	PUMP HOUSING PNR-PNE 104	1
	1601605500	VANE PNE 104	5		16875019E0	PUMP HOUSINGPNR-PNE 124	1
	1601605600	VANE PNE 124	5	47	1691000000	CONVEYOR SPRING	1
3	1605500100	HANDLE	1	48	18930008E0	CLAPET	1
4	16081001E0	DISTRIBUTOR	1	49	4022200030	SEAL 41X27X10	1
5	1608502500	CONVEYOR	1	50	4022200040	SEAL 72X40X10	1
6	1610508500	AUTOMATIC LUBRICATION PUMP FLANGE	1	51	4022200111	SEAL 72X48X15	1
7	1610508700	GEARBOX FLANGE	1	52	4022200113	SEAL 70X55X15	1
8	16120820E0	AIR INJECTION PIPES BRACKET	2	53	4022200309	O-RING 4875 VITON	2
9	16120854E0	DISTRIBUTOR BRACKET	1	54	4022300001	NYLON FILTER	1
10	16125006E0	OIL TANK	1	55	4022301001	SILENCER-FILTER ¼	1
11	1612503500	GEARBOX	1	56	4022301004	SILENCER-FILTER ¾	2
12	1621503500	ROTOR PNR/PNE 104	1	57	4023100018	BEARING 6206 (MULT. 540)	1
	1621503600	ROTOR PNR/PNE 124	1		4023100020	BEARING 6207 (MULT. 1000)	1
13	1622002600	SHAFT	1	58	4023100040	BEARING 6308	2
14	1623100500	CONVEYOR	1	59	4023100046	BEARING 6309	1
15	1624007500	BUSHING 40X48X22	1	60	4023130035	BUSHING 55X45X22	1
16	162409YKB0	SPACER	1	61	4024251000	AUTOM. LUBRICATION PUMP CW ROTATION	1
17	1624202300	SPACER	1		4024251500	AUTOM. LUBRICATION PUMP CCW ROTATION	1
18	16275006E0	MANIFOLD	1	62	4026102702	SCREW TE M 6X12 GALV.	5
19	16401008E0	CLAPET CAP	1	63	4026102704	SCREW TE M 6 X 16 GALV.	4
20	1640101200	OIL TANK CAP	1	64	4026102802	SCREW TE M 8X12 GALV.	3
21	1642600000	PIPELINE PROTECTION	2	65	4026102807	SCREW TE M 8 X 25 GALV.	24
22	1650014500	FRONT SHAFT	1	66	4026102808	SCREW TE M 8 X 30 GALV.	7
23	1650014800	REAR SHAFT	1	67	4026121305	SCREW TCEI M 6 X 16 GALV.	2
24	1651005500	PINION	1	68	4026121401	SCREW TCEI M 8 X 12 GALV.	2
25	1651005700	GEAR	1	69	4026121407	SCREW TCEI M 8 X 25 GALV.	16
26	1663014000	AIR INJECTION PIPE	2	70	4026135414	SCREW M 8X45 GALV.	1
27	1663041100	SUCTION LINE FOR AUT. LUBR. PUMP	1	71	4026135504	SCREW M 10 X 10 GALV.	1
28	16631025E0	FRONT LUBRICATING LINE PNR-E 104 M CW	1	72	4026300020	COMPENSATION RING	1
	16631024E0	FRONT LUBRICATING LINE PNR-E 104 M CCW	1	73	4026300025	COMPENSATION RING	1
	16631021E0	FRONT LUBRICATING LINE PNR-E 124 M CW	1	74	4026306115	NUT M 36X3 ESAG. AUTOBL.	1
	16631020E0	FRONT LUBRICATING LINE PNR-E 124 M CCW	1	75	4026308005	NUT M 8 ESAG. GALV.	2
29	16631024E0	REAR LUBRICATING LINE PNR-E 104 M CW	1	76	4026350505	WASHER GROWER 8 GALV.	16
	16631025E0	REAR LUBRICATING LINE PNR-E 104 M CCW	1	77	4026351504	WASHER M 6 GALV.	2
	16631020E0	REAR LUBRICATING LINE PNR-E 124 M CW	1	78	4026351505	WASHER M 8 GALV.	29
	16631021E0	REAR LUBRICATING LINE PNR-E 124 M CCW	1	79	4026356002	WASHER 8X24 GALV.	3
30	16631028E0	FRONT OIL DRIPPER LINE PNR-E 104 M CW	1	80	4026357003	WASHER M6 GALV.	4
	16631022E0	FRONT OIL DRIPPER LINE PNR-E 104 M CCW	1	81	4026359006	ALU WASHER 13.5X18X1.5	2
	16631026E0	FRONT OIL DRIPPER LINE PNR-E 124 M CW	1	82	4026501003	TAB 12X8X40	1
	16631018E0	FRONT OIL DRIPPER LINE PNR-E 124 M CCW	1	83	4026701301	FITTING	2
31	16631029E0	REAR OIL DRIPPER LINE PNR-E 104 M CW	1	84	4026702004	FITTING	2
	16631023E0	REAR OIL DRIPPER LINE PNR-E 104 M CCW	1	85	4026702708	FITTING 1"½	1
	16631027E0	REAR OIL DRIPPER LINE PNR-E 124 M CW	1	86	4026706000	FITTING 90° 4X1/8	2
	16631019E0	REAR OIL DRIPPER LINE PNR-E 124 M CCW	1	87	4026706003	FITTING 90° 6X1/8	3
32	1672001600	SCREW TCEI M10X1,5	10	88	4026706101	ADJUSTABLE FITTING	2
33	1680609700	OIL PUMP GASKET	1	89	4026740011	REDUCED NIPPLE G1/4	1
34	1680609800	OIL PUMP FLANGE GASKET	1	90	4026904005	PLUG 1"½	1
35	16807009E0	SUCTION GASKET	1	91	4027409920	ONE-WAY VALVE G1/4	1
36	16807010E0	DISCHARGE GASKET	1	92	4029602806	DRIVE SHAFT PROTECTION	1
37	16807011E0	CLAPET CAP GASKET	1				
38	1680707600	GEARBOX GASKET	1		18920027E0	GASKETS KIT	1
39	1680707700	OIL TANK GASKET	1				
40	1680707800	CONVEYOR GASKET	1				
41	1683600300	OIL STICK	1				
42	1684000000	DRAIN PLUG 3/8	4				
43	1685002800	WASHER FE 30X8,5 SP.4	1				

PNR-PNE MULTIPLIER 1000

M1	1610514000	GEARBOX	1	M5	1680614100	GEARBOX GASKET	1
M2	1640501200	FRONT CAP	1	M6	1681006500	PLATE	1
M3	1651010600	GEAR (MULTIPLIER 1000)	1	M7	4026155505	SCREW TSPEI 5X16 GALV.	4
M4	1651010700	PINION (MULTIPLIER 1000)	1	M8	4026401806	PIN 10X36	4

PNR 142 D




IN FIGURA
PNR 142 PRESA DIRETTA

PNR 142 D

Pos.	Code	Description	Q.ty	Pos.	Code	Description	Q.ty
1	1401200700	OIL DRIPPER AUTOMATIC LUBRICATION	2	46	1687509500	PUMP HOUSING PNR 142 SL	1
2	14933006E0	AIR INJECTION VALVE 1/2"	2	47	1687600000	OIL TANK	1
3	1601605200	VANE	5	48	1691000000	CONVEYOR SPRING	1
4	1605500100	HANDLE	1	49	18930008E0	CLAPET	1
5	1608100000	DISTRIBUTOR	1	50	4022200030	SEAL	1
6	1608502500	CONVEYOR	1	51	4022200044	SEAL 65X45X8	1
7	1610508100	GEARBOX FLANGE	2	52	4022200113	SEAL 70X55X15	2
8	1610508200	FLANGE	1	53	4022200311	O-RING 4975	2
9	1610512900	AUTOMATIC LUBRICATION PUMP FLANGE	1	54	4022300001	NYLON FILTER	1
10	1621503200	ROTOR PNR142	1	55	4022301004	SILENCER-FILTER	2
11	1622002600	SHAFT	1	56	4023100046	BEARING 6309	2
12	1623100500	CONVEYOR CAP	1	57	4023130035	BUSCHING 55X45X22	2
13	162409YKB0	SPACER	1	58	4024251000	AUTOM. LUBRICATION PUMP CW ROTATION	1
14	1624042800	SPACER	2		4024251500	AUTOM. LUBRICATION PUMP CCW ROTATION	1
15	1624202300	SPACER	1	59	4026101301	SCREW TE M6X10 GALV.	2
16	1626001100	BUSHING	1	60	4026102804	SCREW TE M8X16 GALV.	3
17	16275007E0	MANIFOLD	1	61	4026102807	SCREW TE M8X25 GALV.	16
18	16401008E0	CLAPET CAP	1	62	4026102808	SCREW TE M8X30 GALV.	2
19	1642100200	REAR PROTECTION	1	63	4026102907	SCREW TE M10X25 GALV.	16
20	1642600100	DRIVE SHAFT PROTECTION	1	64	4026121305	SCREW TCEI M6X16 GALV.	2
21	1650013100	FRONT SMOOTH SHAFT	1	65	4026121401	SCREW TCEI M8X12 GALV.	2
	1650012900	FRONT SPLINED SHAFT	1	66	4026121407	SCREW TCEI M8X25 GALV.	8
22	1650022900	REAR SHAFT	1	67	4026121710	SCREW TCEI M12X35 GALV.	2
23	1663014000	AIR INJECTION PIPE	2	68	4026135414	SCREW M8X45 GALV.	1
24	1663065800	PIPE OIL DRIPPER-FRONT FLANGE L	1	69	4026135504	SCREW M10X10 GALV.	1
25	1663065900	PIPE OIL DRIPPER-REAR FLANGE L	1	70	4026155605	SCREW TSPEI M6X16 GALV.	4
26	1663066000	PIPE FRONT FLANGE-PUMP HOUSING L	1	71	4026171211	SCREW M12X80 GALV.	2
27	1663066100	PIPE REAR FLANGE-PUMP HOUSING L	1	72	4026300025	COMPENSATION RING	2
28	1663066300	PIPE OIL TANK-HOUSE PUMP R	1	73	4026305508	NUT M12 ESAG. AUTOBLOCC.	2
29	1663066400	PIPE PUMP-OIL DRIPPER	1	74	4026308005	NUT M 8 ESAG. GALV.	2
30	1663066500	PIPE PUMP-OIL DRIPPER	1	75	4026350505	WASHER GROWER 8 GALV.	20
31	1672001600	SCREW TCEI M10X1,5	10	76	4026350508	WASHER GROWER 12 GALV.	2
32	1673001000	OIL FILTER PLUG	1	77	4026351504	WASHER 6 GALV.	4
33	1680609700	OIL PUMP GASKET	1	78	4026351505	WASHER 8 GALV.	8
34	1680610200	MANIFOLD GASKET	2	79	4026351506	WASHER 10 GALV.	16
35	1680707300	FRONT FLANGE GASKET	2	80	4026356002	WASHER 8X24 GALV.	3
36	1680707800	CONVEYOR GASKET	1	81	4026357007	WASHER M12 GALV.	2
37	16807011E0	CLAPET CAP GASKET	1	82	4026501006	TAB 12X8X56	1
38	1681006600	FLANGE	2	83	4026701301	FITTING 1/2X18	2
39	1681100200	OIL DRIPPER FLANGE	1	84	4026702000	FITTING 4X1/8	8
40	1684000000	PLUG 3/8	2	85	4026706000	FITTING UNIV.90° 4X1/8	2
41	1685002800	WASHER 30X8,5 GALV.	1	86	4026706003	FITTING UNIV.90° 6X1/8	2
42	1685100000	ALU WASHER	2	87	4026706101	FITTING 4-1/8	2
43	1685100200	WASHER	2	88	4026904503	PLUG	1
44	1685100300	WASHER	2	89	4026910103	PLUG	1
45	1685100800	WASHER	2	90	4026910601	PLUG 1/8'	2

Pos.	Code	Description	Q.ty	Pos.	Code	Description	Q.ty
1		FLANGED MANIFOLD		2		THREADED MANIFOLD	
F1	1627504800	FLANGED MANIFOLD	1	F2	1627504900	THREADED MANIFOLD	1
F3	4026351505	WASHER M8	12	F3	4026351505	WASHER M8	12
F4	4026102807	SCREW M8X25	12	F4	4026102807	SCREW M8X25	12
F5	4026135504	SCREW M10X10	1	F5	4026135504	SCREW M10X10	1


PNR 142 WITH MULTIPLIER



PNR 142 M

Pos.	Code	Description	Q.ty	Pos.	Code	Description	Q.ty
1	1401200700	OIL DRIPPER	2	59	4022301004	SILENCER-FILTER	2
2	14933006E0	AIR INJECTION VALVE 1/2"	2	60	4023100018	BEARING 6206 MULT. 540	1
3	1601605200	VANE	5		4023100020	BEARING 6206 MULT. 1000	1
4	1605500100	HANDLE	1	61	4023100040	BEARING 6308	1
5	1608100000	DISTRIBUTOR	1	62	4023100150	BEARING 6309	2
6	1608502500	CONVEYOR	1	63	4023130035	BUSHING 55X45X22	2
7	1610507900	GEARBOX FLANGE	1	64	4024251000	AUTOM. LUBRICATION PUMP CW ROTATION	1
8	1610508100	FLANGE	1		4024251500	AUTOM. LUBRICATION PUMP CCW ROTATION	1
9	1610512900	AUTOMATIC LUBRICATION PUMP FLANGE	1	65	4026101301	SCREW TE M6X10 GALV.	2
10	1612503000	GEARBOX	1	66	4026102804	SCREW TE M8X16 GALV.	3
11	1621503200	ROTOR	1	67	4026102807	SCREW TE M8X25 GALV.	13
12	1622002600	SHAFT	1	68	4026102808	SCREW TE M8X30 GALV.	9
13	1623100500	CONVEYOR CAP	1	69	4026102907	SCREW TE M10X25 GALV.	13
14	162409YKB0	SPACER	1	70	4026120506	SCREW TCEI M10X30 GALV.	1
15	1624042800	SPACER	2	71	4026121305	SCREW TCEI M6X16 GALV.	2
16	1624202300	SPACER	1	72	4026121401	SCREW TCEI M8X12 GALV.	2
17	16275007E0	MANIFOLD	1	73	4026121407	SCREW TCEI M8X25 GALV.	8
18	16401008E0	CLAPET CAP	1	74	4026121710	SCREW TCEI M12X35 GALV.	2
19	1642100200	REAR PROTECTION	1	75	4026121813	SCREW TCEI M10X50 GALV.	2
20	1642600100	DRIVE SHAFT PROTECTION	1	76	4026135414	SCREW M8X45 GALV.	1
21	1650012800	FRONT SHAFT	1	77	4026135504	SCREW M10X10 GALV.	1
22	1650022900	REAR SHAFT	1	78	4026155505	SCREW TSPEI M5X16 GALV.	4
23	1651005200	GEAR	1	79	4026155605	SCREW TSPEI M6X16 GALV.	4
24	1651005300	PINION Z 25	1	80	4026171211	SCREW M12X80 GALV.	2
25	1663014000	AIR INJECTION PIPE	1	81	4026300025	COMPENSATION RING	2
26	1663065800	PIPE OIL DRIPPER-FRONT FLANGE L	1	82	4026305508	NUT M12 ESAG. AUTOBLOCC.	2
27	1663066000	PIPE FRONT FLANGE-PUMP HOUSING L	1	83	4026306115	NUT M36X3 ESAG. AUTOBL.	1
28	1663066300	PIPE OIL TANK-PUMP R	1	84	4026308005	NUT M 8 ESAG. ZINC.	2
29	1663066400	PIPE PUMP-OIL DRIPPER	1	85	4026350505	WASHER GROWER 8 GALV.	20
30	1663066500	PIPE PUMP-OIL DRIPPER	1	86	4026350506	WASHER GROWER 10 GALV.	2
31	1663066700	PIPE OIL DRIPPER-PUMP	1	87	4026350508	WASHER 12 GALV.	2
32	1672001600	SCREW TCEI M10X1,5	10	88	4026351504	WASHER 6 GALV.	4
33	1673001000	OIL FILTER PLUG	2	89	4026351505	WASHER 8 GALV.	10
34	1680609700	OILP UMP GASKET	1	90	4026351506	WASHER 10 GALV.	13
35	1680610200	MANIFOLD GASKET	2	91	4026356002	WASHER 8X24 GALV.	3
36	16807011E0	CLAPETC AP GASKET	1	92	4026357007	WASHER M12 GALV.	2
37	1680707200	GEARBOX FLANGE	1	93	4026501004	TAB 12X8X45	1
38	1680707300	FRONT FALNGE GASKET	1	94	4026701301	FITTING 1/2X18	2
39	1680707800	CONVEUOR GASKET	1	95	4026702000	FITTING 4X1/8	6
40	1681006500	PLATE	1	96	4026706000	FITTING UNIV.90° 4X1/8	2
41	1681006600	PLATE	2	97	4026706003	FITTING UNIV.90° 6X1/8	2
42	1681100200	OILD RIPPER FLANGE	1	98	4026706101	FITTING 4-1/8	2
43	1684000000	PLUG 3/8	5	99	4026904503	PLUG	1
44	1685002800	WASHER 30X8,5 GALV.	1	100	4026910103	PLUG	1
45	1685100000	ALU WASHER	2	101	4026910601	PLUG 1/8"	2
46	1685100100	WASHER	1				
47	1685100200	WASHER	5			PNR WITH MULTIPLIER 1000	
48	1685100300	WASHER	2	M1	1610514100	GEARBOX FLANGE	1
49	1685100800	WASHER	2	M2	164059V5B0	FRONTC OVER	1
50	1687509500	PUMP HOUSING PNR 142 SL	1	M3	165109KFB0	PINION 1000	1
51	1687600000	OIL TANK	1	M4	165109KGB0	GEAR	1
52	1691000000	CONVEYOR SPRING	1	M5	16807BCNB0	GEARBOX GASKET	1
53	18930008E0	CLAPET	1	M6	4026102810	SCREW TE M8X40 GALV.	8
54	4022200030	SEAL	1	M7	4026401806	PIN 10X36	4
55	4022200040	SEAL 72X40X10	1				
56	4022200113	SEAL 70X55X15	2				
57	4022200311	O-RING 4975	2				
58	4022300001	NYLON FILTER	2				

PNR/PNE 73-83-104-124 HYD AND ACCESSORIES



PICTURE SHOWS
PNR 104 HDR

COD. E698109440

PICTURE SHOWS
PNR 73 HDR

COD. E738109440


PNR/PNE 73-83 HYD and accessories

Pos.	Code	Description	Q.ty	Pos.	Code	Description	Q.ty
H1	1470102900	COUPLING	1	P11	4022200330	O-RING 3375	1
H2	16100396E0	HYD FLANGE	1	P12	4022200331	O-RING 2137	1
H3	1612501000	HYD BRACKET	1	P13	4026102804	SCREW TE M8X16 GALV.	4
H4	1680700400	FLANGE GASKET	1	P14	4026102807	SCREW TE M8X25 GALV.	4
H5	4024107008	HYD MOTOR PNR73-83	1	P15	4026121405	SCREW TCEI M8X20 GALV.	4
H6	4026103004	SCREW TE M12X40 GALV.	4	P16	4026350505	WASHER GROWER 8 GALV	4
H7	4026102807	SCREW TE M8X25 GALV.	3	P17	4026351505	WASHER M8 GALV.	8
H8	4026136004	SCREW 14.9 M8X10 GALV.	1	P18	4027100405	PNEUMATIC ACTUATOR	1
H9	4026136006	SCREW 14.9 M8X14 GALV.	1				
H10	4026171304	SCREW M14X40	4		14302033E0	HYDRAULIC OPERATED 4-WAY KIT	
H11	4026308008	NUT M14 ESAG. GALV.	4	I1	14302031E0	HYDRAULIC ACTUATOR	1
H12	4026350709	WASHER GROWER 12 GALV.	4	I2	160858KNB0	INSIDE VALVE	1
H13	4026350710	WASHER GROWER 14 GALV.	4	I3	16100416E0	HYDRAULIC ACTUATOR FLANGE	1
H14	4026351505	WASHER M8	3	I4	161258B4B0	SUPPORT FLANGE	1
H15	4026359001	ALU. WASHER 33,5X40X1,5	1	I5	1640580QB0	COVER	1
H16	4026510540	SEEGER I 72	1	I6	167007ZAB0	NUT	1
H17	4026711002	FLANGE ASF 102G 1"	1	I7	16732001E0	COUPLER	1
H18	4026711003	FLANGE ASF 104G 1"1/4	1	I8	1680700200	CONVEYOR-CAP GASKET	1
H19	4026904003	PLUG 1" ZINC.	1	I9	168409PQB0	RING NUT	1
				I10	168529TFB0	SPACER	1
A	185219N7B0	SUCTION FILTER KIT PNR/E 73-83		I11	1691000200	SPRING	1
	1852108800	FIXED SUCTION CONVEYOR Ø60		I12	4022100100	GREASER M6X1	1
B1	1627100100	CONVEYOR Ø60	1	I13	4022200005	Y-SEAL 37X27X7	1
B2	4022200307	O-RING	1	I14	4022200027	Y-SEAL 55X40X8	1
B3	4026103002	SCREW TE M12X30 GALV.	4	I15	4022200330	O-RING 3375	1
B4	4026350709	WASHER GROWER 12 GALV.	4	I16	-	-	-
	1852108900	FIXED SUCTION CONVEYOR Ø76		I17	4026102804	SCREW TE M8X16 GALV.	4
B1	1627100200	CONVEYOR Ø76	1	I18	4026102807	SCREW TE M8X25 GALV.	4
B2	4022200307	O-RING	1	I19	4026102911	SCREW TE M10X45 GALV.	2
B3	4026103002	SCREW TE M12X30 GALV.	4	I20	4026121405	SCREW TCEI M8X20 GALV.	4
B4	4026350709	WASHER GROWER 12 GALV.	4	I21	4026136209	GRUB SCREW M6X20	1
	1852108600	FIXED SUCTION CONVEYOR Ø80		I22	4026312B01	WASHER DA 8	4
B1	1627100300	CONVEYOR Ø80	1	I23	4026301503	WASHER GROWER 10 GALV.	1
B2	4022200307	O-RING	1	I24	4026350708	WASHER M8 GALV.	2
B3	4026103002	SCREW TE M12X30 GALV.	4	I25	4026351505	SCREW TE M8X25 GALV.	8
B4	4026350709	WASHER GROWER 12 GALV.	4	I26	4029602700	GREASER PROTECTION	1
	1852104800	TURNING CONVEYOR Ø76					
C1	1610100000	CONVEYOR FLANGE	1				
C2	1627100500	CONVEYOR Ø76	1				
C3	4022200307	O-RING	1				
C4	4026103002	SCREW TE M12X30 GALV.	4				
C5	4026350709	WASHER GROWER 12 GALV.	4				
	1430282DB0	PNEUMATIC OPERATED 4-WAY KIT					
P1	1608582NB0	CONVEYOR	1				
P2	161258B4B0	ACTUATOR SUPPORT	1				
P3	1640580QB0	ACTUATOR COVER	1				
P4	167007ZAB0	CONVEYOR NUT	1				
P5	1680700200	FALNGE GASKET	1				
P6	168409PQB0	RING NUT	1				
P7	168529TFB0	SPACER	1				
P8	1691000200	CONVEYOR SPRING	1				
P9	4022100100	GREASING NIPPLE M6X1	1				
P10	4022200005	Y-SEAL 37X27X7	1				

PNR/PNE 104-124 HYD and accessories

Pos.	Code	Description	Q.ty	Pos.	Code	Description	Q.ty
H1	1470102300	COUPLING	1	D3	4026102810	SCREW TE M8X40 GALV.	4
H2	1610021600	HYD FLANGE	1	D4	4026308005	NUT M8 ESAGONALE GALV.	4
H3	1612501000	HYD BRACKET	1	D5	4026350706	WASHER GROWER 8 ZINC.	8
H4	1680707300	FRONT FLANGE GASKET	1				
H5	4024107009	HYD MOTOR PNR104	1		1852104100	KIT FOR SAFETY VALVE	
	4024107001	HYD MOTOR PNR124	1	E1	1627102500	CONVEYOR WITH SAFETY VALVE CONNECTION	1
H6	4026103004	SCREW M12X40 GALV.	4	E2	4022200310	O-RING 6362	1
H7	4026121405	SCREW M8X20 GALV.	3	E3	4026102810	SCREW TE M8X40 GALV.	4
H8	4026136003	SCREW M8X8	1	E4	4026308005	NUT M8 ESAGONALE GALV.	4
H9	4026136006	SCREW M8X14	1	E5	4026350706	WASHER GROWER 8 ZINC.	8
H10	4026171304	SCREW M14X40	4				
H11	4026308008	NUT M14 GALV.	4		1430280PB0	KIT PNEUMATIC ACTUATOR	
H12	4026350709	WASHER GROWER 12 GALV.	4	P1	1608581CB0	CONVEYOR	1
H13	4026350710	WASHER GROWER 14 GALV.	4	P2	161258H0B0	ACTUATOR SUPPORT	1
H14	4026350909	WASHER M8	3	P3	1640580QB0	ACTUATOR COVER	1
H15	4026359001	WASHER 40X33,5X1,5	1	P4	167007ZAB0	CONVEYOR NUT	1
H16	4026711003	FLANGE ASF 104G 1"1/4	1	P5	1680707800	GASKET	1
H17	4026711004	FLANGE AFS 106G 1"1/2	1	P6	168409PQB0	RING NUT	1
H18	4026904003	PLUG 1" ZINC.	1	P7	168529TFB0	SPACER	1
				P8	1691000200	CONVEYOR SPRING	1
A	185212L4B0	SUCTION FILTER KIT PNR/E 104-124		P9	4022100100	GREASING NIPPLE M6X1	1
				P10	4022200005	Y-SEAL 37X27X7	1
	1852103300	FIXED SUCTION CONVEYOR Ø76		P11	4022200330	O-RING 3375	1
B1	1627102000	CONVEYOR Ø76	1	P12	4022200331	O-RING 2137	1
B2	4022200310	O-RING 6362	1	P13	4026102804	SCREW TE M8X16 GALV.	4
B3	4026102807	SCREW TE M8X25 GALV.	4	P14	4026102807	SCREW TE M8X25 GALV.	4
B4	4026350706	WASHER GROWER 8 GALV.	4	P15	4026121405	SCREW TCEI M8X20 GALV.	4
	1852103400	FIXED SUCTION CONVEYOR Ø80		P16	4026350505	WASHER GROWER 8 GALV.	4
B1	1627101300	CONVEYOR Ø80	1	P17	4026351505	WASHER M8 GALV.	8
B2	4022200310	O-RING 6362	1	P18	4027100405	PNEUMATIC ACTUATOR	1
B3	4026102807	SCREW TE M8X25 GALV.	4				
B4	4026350706	WASHER GROWER 8 GALV.	4		14302032E0	HYDRAULIC OPERATED 4-WAY KIT	
	1852103500	FIXED SUCTION CONVEYOR Ø100		I1	14302031E0	HYDRAULIC ACTUATOR	1
B1	1627101200	CONVEYOR Ø100	1	I2	160858KBB0	INSIDE VALVE	1
B2	4022200310	O-RING 6362	1	I3	16100416E0	HYDRAULIC ACTUATOR FLANGE	1
B3	4026102807	SCREW TE M8X25 GALV.	4	I4	161258H0B0	SUPPORT FLANGE	1
B4	4026350706	WASHER GROWER 8 GALV.	4	I5	1640580QB0	COVER	1
	1852103800	TURNING CONVAYOR Ø76 KIT		I6	167007ZAB0	NUT	1
C1	1610101100	CONVEYOR FLANGE	1	I7	16732001E0	COUPLER	1
C2	1627102800	CONVEYOR	1	I8	1680707800	CONVEYOR-CAP GASKET	1
C3	4022200310	O-RING 6362	1	I9	168409PQB0	RING NUT	1
C4	4026102808	SCREW TE M8X30 GALV.	4	I10	168529TFB0	SPACER	1
C5	4026350706	WASHER GROWER 8 GALV.	4	I11	1691000200	SPRING	1
	1852103900	TURNING CONVAYOR Ø80 KIT		I12	4022100100	GREASER M6X1	1
C1	1610101100	CONVEYOR FLANGE	1	I13	4022200005	Y-SEAL 37X27X7	1
C2	1627102700	CONVEYOR	1	I14	4022200027	Y-SEAL 55X40X8	1
C3	4022200310	O-RING 6362	1	I15	4022200330	O-RING 3375	1
C4	4026102808	SCREW TE M8X30 GALV.	4	I16	4022301000	SILENCER-FILTER 1/8 GAS	1
C5	4026350706	WASHER GROWER 8 GALV.	4	I17	4026102804	SCREW TE M8X16 GALV.	4
	1852104000	TURNING CONVAYOR Ø100 KIT		I18	4026102807	SCREW TE M8X25 GALV.	4
C1	1610101100	CONVEYOR FLANGE	1	I19	4026102911	SCREW TE M10X45 GALV.	2
C2	1627102400	CONVEYOR	1	I20	4026121405	SCREW TCEI M8X20 GALV.	4
C3	4022200310	O-RING 6362	1	I21	4026136213	GRUB SCREW M6X40	1
C4	4026102808	SCREW TE M8X30 GALV.	4	I22	4026312B01	WASHER DA 8	4
C5	4026350706	WASHER GROWER 8 GALV.	4	I23	-	-	-
	1852104200	KIT CONVEYOR		I24	4026350708	WASHER GROWER 10 GALV.	2
D1	1627102600	CONVEYOR	1	I25	4026351505	WASHER M8 GALV.	8
D2	4022200310	O-RING 6362	1	I26	4029602700	GREASER PROTECTION	1

PNR 142 HYD AND ACCESSORIES




PNR 142 HYD and accessories

Pos.	Code	Description	Q.ty	Pos.	Code	Description	Q.ty
H1	1470102300	COUPLING	1	A	185212L4B0	KIT SUCTION FILTER	
H2	1610021600	HYD FLANGE	1		1852103400	FIXED CONVEYOR Ø80	
H3	1612501000	BRACKET HYD	1	B1	1627101300	CONVEYOR Ø80	1
H4	1680707300	GASKET	1	B2	4022200310	O-RING 6362	1
H5	4024107004	HYD MOTOR	1	B3	4026102807	SCREW M8X25 GALV.	4
H6	4026103004	SCREW M12X40 GALV.	4	B4	4026350706	WASHER GROWER M8	4
H7	4026121405	SCREW M8X20 GALV.	3		1852103500	FIXED CONVEYOR Ø100	
H8	4026136003	SCREW M8X8 GALV.	1	B1	1627101200	CONVEYOR Ø100	1
H9	4026136006	SCREW M8X14 GALV.	1	B2	4022200310	O-RING 6362	1
H10	4026141304	SCREW M14X40 GALV.	4	B3	4026102807	SCREW M8X25 GALV.	4
H11	4026350709	WASHER GROWER M12	4	B4	4026350706	WASHER GROWER M8	4
H12	4026350710	WASHER GROWER M14	4				
H13	4026308008	NUT M14	4				
H14	4026350505	WASHER GROWER M8	3				
H15	4026359001	WASHER	1				
H16	4026904003	PLUG 1"	1				

1852103900 TURNING CONVEYOR Ø80				I11	1691000200	SPRING	1
C1	1610101100	CONVEYOR FLANGE	1	I12	4022100100	GREASER M6X1	1
C2	1627102700	CONVEYOR	1	I13	4022200005	Y-SEAL 37X27X7	1
C3	4022200310	O-RING 6362	1	I14	4022200027	Y-SEAL 55X40X8	1
C4	4026102808	SCREW TE M8X30 GALV.	4	I15	4022200330	O-RING 3375	1
C5	4026350706	WASHER GROWER M8 GALV.	4	I16	4022301000	SILENCER-FILTER 1/8 GAS	1
1852104000 TURNING CONVEYOR Ø100				I17	4026102804	SCREW TE M8X16 GALV.	4
C1	1610101100	CONVEYOR FLANGE	1	I18	4026102807	SCREW TE M8X25 GALV.	4
C2	1627102400	CONVEYOR	1	I19	4026102911	SCREW TE M10X45 GALV.	2
C3	4022200310	O-RING 6362	1	I20	4026121405	SCREW TCEI M8X20 GALV.	4
C4	4026102808	SCREW TE M8X30 GALV.	4	I21	4026136213	GRUB SCREW M6X40	1
C5	4026350706	WASHER GROWER M8 GALV.	4	I22	4026312B01	WASHER DA 8	4
1852104200 KIT CONVEYOR				I23	-	-	-
D1	1627102600	CONVEYOR	1	I24	4026350708	WASHER GROWER 10 GALV.	2
D2	4022200310	O-RING 6362	1	I25	4026351505	WASHER M8 GALV.	8
D3	4026102810	SCREW TE M8X40 GALV.	4	I26	4029602700	GREASER PROTECTION	1
D4	4026308005	NUT M8 ESAGONALE GALV.	4				
D5	4026350706	WASHER GROWER 8 ZINC.	8				
1852104100 KIT FOR SAFETY VALVE							
E1	1627102500	CONVEYOR WITH SAFETY VALVE CONNECTION	1				
E2	4022200310	O-RING 6362	1				
E3	4026102810	SCREW TE M8X40 GALV.	4				
E4	4026308005	NUT M8 ESAGONALE GALV.	4				
E5	4026350706	WASHER GROWER 8 ZINC.	8				
143028GZB0 KIT PNEUMATIC ACTUATOR							
P1	160858KBB0	CONVEYOR	1				
P2	161258H0B0	ACTUATOR SUPPORT	1				
P3	1640580QB0	ACTUATOR COVER	1				
P4	167007ZAB0	CONVEYOR NUT	1				
P5	1680707800	GASKET	1				
P6	168409PQB0	RING NUT	1				
P7	168529TFB0	SPACER	1				
P8	1691000200	CONVEYOR SPRING	1				
P9	4022100100	GREASING NIPPLE M6X1	1				
P10	4022200005	Y-SEAL 37X27X7	1				
P11	4022200330	O-RING 3375	1				
P12	4022200331	O-RING 2137	1				
P13	4026102804	SCREW M8X16 GALV.	4				
P14	4026102807	SCREW M8X25 GALV.	4				
P15	4026121405	SCREW M8X20 GALV.	4				
P16	4026350505	WASHER GROWER M8	4				
P17	4026351505	WASHER M8	8				
P18	4027100405	PNEUMATIC ACTUATOR	1				
P19	4027421206	FITTING	2				
14302032E0 HYDRAULIC OPERATED 4-WAY KIT							
I1	14302031E0	HYDRAULIC ACTUATOR	1				
I2	160858KBB0	INSIDE VALVE	1				
I3	16100416E0	HYDRAULIC ACTUATOR FLANGE	1				
I4	161258H0B0	SUPPORT FLANGE	1				
I5	1640580QB0	COVER	1				
I6	167007ZAB0	NUT	1				
I7	16732001E0	COUPLER	1				
I8	1680707800	CONVEYOR-CAP GASKET	1				
I9	168409PQB0	RING NUT	1				
I10	168529TFB0	SPACER	1				

ACCESSORIES (OUT OF PRODUCTION)

ACCESSORIES (OUT OF PRODUCTION)



Pos.	Code	Description	Q.ty
6	143029KRB0	KIT HYDRAULIC ACTUATOR PNR-E 142	
I1	143027T6B0	HYDRAULIC ACTUATOR	1
I2	15020A10B0	ACTUATOR LEVER	1
I3	151307TJB0	ACTUATOR SUPPORT	1
I4	1608502900	CONVEYOR	1
I5	1623100700	FLANGE	1
I6	1624043400	SPACER	1
I7	162409YKB0	SPACER	1
I8	16242003E0	SPACER	1
I9	164206XYB0	PROTECTION	1
I10	1680707800	GASKET	1
I11	1685002800	WASHER 30X8.5X4	1
I12	168509U0B0	WASHER	1
I13	1691000000	SPRING	1
I14	4022100100	GREASING NIPPLE M6X1	1
I15	4022100107	GREASER	1
I16	4022200030	SEAL	1
I17	4026121405	SCREW M8X20 GALV.	2
I18	4026121408	SCREW M8X35 GALV.	4
I19	4026135414	SCREW M8X45 GALV.	1
I20	4026155705	SCREW M8X16 GALV.	1
I21	4026308005	NUT M8	4
I22	4026350505	WASHER GROWER M8	6
I23	4026510012	SEEGER E14	1

Pos.	Code	Description	Q.ty
	143027T7B0	HYDRAULIC OPERATED 4-WAY KIT	
1	143027T6B0	HYDRAULIC ACTUATOR	1
2	150206XXB0	ACTUATOR LEVER	1
	16240A0IB0	SPACER	1
3	151307TJB0	ACTUATOR SUPPORT	1
4	1608502000	CONVEYOR	1
5	1623100000	CONVEYOR CAP	1
6	-	-	-
7	-	-	-
8	1624202300	SPACER	1
9	164206XYB0	PROTECTION	1
10	1680700200	CONVEYOR CAP GASKET	1
11	1685002800	WASHER FE 30X8,5 SP.4 GALV.	1
12	1685002800	WASHER FE 30X8,5 SP.4 GALV.	1
13	1691000000	CONVEYOR SPRING	1
14	4022100100	GREASING NIPPLE M6X1	1
15	4022200030	Y-SEAL 41X27X10	1
16	4026102804	SCREW TE M8X16 GALV.	1
17	4026102808	SCREW TE M8X30 GALV.	4
18	4026121405	SCREW TCEI M8X20 GALV.	2
19	4026135415	SCREW 14.9 M8X50 GALV.	1
20	4026308005	NUT M8 GALV.	4
21	4026350706	WASHER GROWER 8 GALV.	7
22	4026357005	WASHER M8 GALV.	4
23	4026510012	SEEGER E14	1

Pos.	Code	Description	Q.ty
	143027TEB0	KIT HYDRAULIC ACTUATOR	
1	143027T6B0	HYDRAULIC ACTUATOR	1
2	150206XXB0	ACTUATOR LEVER	1
	16240A0IB0	SPACER	1
3	151307TJB0	ACTUATOR SUPPORT	1
4	1608502100	CONVEYOR	1
5	1623100500	CONVEYOR CAP	1
6	-	-	-
7	-	-	-
8	1624202300	SPACER	1
9	164206XYB0	PROTECTION	1
10	1680707800	CONVEYOR CAP GASKET	1
11	1685002800	WASHER FE 30X8,5 SP.4 GALV.	1
12	1685002800	WASHER FE 30X8,5 SP.4 GALV.	1
13	1691000000	CONVEYOR SPRING	1
14	4022100100	GREASING NIPPLE M6X1	1
15	4022200030	Y-SEAL 41X27X10	1
16	4026102804	SCREW TE M8X16 GALV.	1
17	4026102808	SCREW TE M8X30 GALV.	4
18	4026121405	SCREW TCEI M8X20 GALV.	2
19	4026135415	SCREW M8X50 GALV.	1
20	4026308005	NUT M8 GALV.	4
21	4026350706	WASHER GROWER 8 GALV.	7
22	4026357005	WASHER M8 GALV.	4
23	4026510012	SEEGER E14	1

Model	Issue date	Revision No.	Revision date	Filled out by	Viewed by
PNR/PNE	06-06-2016	04	02-12-2019	U.T.	A.T.

Juop SpA

Via Crosera, 50
33082 Azzano Decimo, PN (ITALY)

Tel. +39 0434 636811
Fax. +39 0434 636812

<http://www.juop.it>
e-mail: info@juop.it

Juop SpA reserves the right to modify the products described in this manual without prior notice.