



**Parts List for 0165, 0205, 0255 and 0305**

<b>Ref</b>	<b>Description</b>	<b>Ref</b>	<b>Description</b>	<b>Ref</b>	<b>Description</b>
1	Cylinder	143	Lockwasher	313	Coupling half, pump side
5	Set screw plug	146	Hex head cap screw	319	Motor spacer
15	Rotor	149	Socket head cap screw	321	Fan
18	Bearing sleeve	150	Lockwasher	322	Axial fan
22	Vane	152	Lockwasher	326	Retainer ring
25	Endplate, motor side	153	Exhaust adapter	353	Socket head cap screw
26	Endplate, fan side	154	Exh. cover adapter gasket	360	Lockwasher
30	Needle bearing	159	Exhaust valve	390	Eye bolt adapter
31	Endplate spacer	162	Oil fill elbow gasket	391	Eye bolt
35	Shaft seal	169	Valve cover plate	392	Lockwasher
42	Shaft seal retaining plate	171	Insert, gas ballast	393	Hex head screw
43	Screw, hex head	175	Socket head cap screw	400	Motor
49	O-ring	176	Lockwasher	401	Screw, hex head cap
50	O-ring	185	Gasket, cylinder/exh. box	402	Lockwasher
53	Screw, hex head	189	Stud	417	Set screw
54	Lockwasher	190	Lockwasher	421	Foot, rubber
57	Hex head screw	191	Nut	422	Foot, rubber
58	Lockwasher	194	Level switch	429	Screw
60	Taper pin	195	Level switch support	430	Name plate
65	Shaft key	196	Socket set screw	431	Label "arrow"
66	Shaft key	197	O-ring	470	Hyd. fitting banjo
75	Exhaust box	198	Socket head screw	471	Tubing, gas ballast
80	Sheet metal baffle	205	Exh. cover side plate	472	Hyd. fitting, straight
83	Oil sight glass	206	Exh. cover plate gasket	474	Filter, gas ballast
84	Gasket, oil sight glass	207	Socket head cap screw	475	Bracket
87	Elbow, oil fill	208	Lockwasher	476	Elbow
88	Oil fill plug	224	Pipe adapter	477	Bell valve
89	Gasket ring, fill plug	225	Hydraulic fitting	478	Hex head cap screw
90	Exhaust pressure gauge	228	Hydraulic fitting	480	Oil tube insert
92	Socket head plug	230	Oil tubing	9000	Plug, socket
95	Oil drain plug	238	Socket head cap screw	9011	Endplate spacer
96	O-ring	239	Lockwasher		
99	Pipe nipple	241	Oil cooler		
100	Oil filter, automotive type	242	O-ring		
105	Cover, exhaust box	244	Fan cover		
106	Gasket, exhaust box cover	247	Socket head cap screw		
107	Hex head cap screw	250	Flange, lower, inlet		
108	Lockwasher	251	Valve plate, inlet		
115	Exhaust filter grip plate	252	Valve plate guide		
118	Filter support	253	O-ring		
119	O-ring	254	Spring, valve plate		
120	Exhaust filter	255	O-ring		
121	O-ring	260	Inlet flange, upper		
126	Screw, socket head cap	261	Inlet screen		
127	Distance sleeve	265	Screw, hex head cap		
128	Lockwasher	266	Lockwasher		
130	Baffle strainer	270	Hyd. fitting, elbow		
131	Stud	290	Oil return line		
132	Washer	291	Hyd. fitting, elbow		
133	Filter support tube	300	Motor mounting bracket		
134	Hex nut	301	Screw hex head cap		
136	Exh. baffle strainer screen	302	Lockwasher		
137	Distance sleeve	306	Motor adapter flange		
140	Exhaust cover plate	307	Socket head screw		
141	Exhaust cover gasket	311	Coupling half, motor side		
142	Socket head cap screw	312	Coupling insert		