



Parts List for R 5 0502/0630

Ref	Description	Ref	Description	Ref	Description
001	Cylinder	141	Cover plate gasket	313	Pump side coupling half
004	Stud	142	Hex head cap screw	319	Spacer
005	Set screw	143	Lockwasher	320	Fan and coupling spacer
008	Stud	146	Hex head cap screw	321	Pump shaft fan
009	Stud	153	Cover plate exhaust screen	327	Locking disk
015	Rotor	159	Exhaust valve	328	Socket head cap screw
018	Bearing sleeve	168	O-ring	329	Lockwasher
019	Shaft seal sleeve	169	Exh. valve cover plate	350	Centering ring
022	Vane	175	Hex head cap screw	351	Centering ring
025	Motor side endplate	176	Lockwasher	352	Fan guard
026	Opp. M.S. endplate	184	Socket head cap screw	353	Hex head cap screw
030	Needle bearing	185	Cylinder/Exhaust box gasket	354	Hex head nut
035	Shaft seal	186	Hex head cap screw	355	Distance bolt
039	Socket head mach. screw	187	Lockwasher	356	Mounting bolt
040	Protective screen	200	Drum exhaust box plug	357	Hex nut
041	Hex head nut	201	O-ring	358	Lockwasher
042	Shaft seal support ring	205	Cover side plate	360	Lockwasher
043	Hex head cap screw	206	Gasket	391	Eyebolt
046	Hex head plug	207	Hex head cap screw	400	Motor
047	Copper ring gasket	222	Hydraulic elbow fitting	401	Hex head cap screw
050	O-ring	223	Hydraulic elbow fitting	417	Slotted set screw
053	Hex head cap screw	224	Hydraulic banjo fitting	418	Rubber foot
054	Lockwasher	225	Hydraulic straight fitting	419	Foot spacer
056	Hex head cap nut	226	Hydraulic banjo fitting	420	Stud
060	Tapered pin	230	Oil tubing	421	Rubber foot
065	Shaft key	231	Oil tubing	422	Rubber foot
066	Shaft key	232	Oil tubing	423	Lockwasher
075	Exhaust box	233	Oil tubing	424	Hex head cap nut
078	Sheet metal baffle	236	Hydraulic fitting	430	Nameplate
079	Demister pad	238	Hex head nut	431	Arrow label
080	Perforated sheet metal	239	Lockwasher	436	Maintenance label
083	Oil sight glass	241	Oil cooler	470	Hydraulic banjo fitting
084	Ring gasket	250	Inlet flange	471	Teflon tubing
088	Oil fill plug	251	Valve plate	472	Check valve
089	Oil fill plug gasket	252	Valve inlet guide	473	Bell reducer
090	Pressure gauge	253	O-ring	474	Gas ballast filter
095	Oil drain plug	254	Inlet check valve spring	475	Gas ballast valve bracket
096	O-ring	255	O-ring	476	Elbow fitting
099	Nipple	258	Ball, Viton	477	Pet cock valve
100	Auto-type oil filter	260	Inlet flange	478	Hex head cap screw
105	Cover plate	261	Inlet screen	479	Lockwasher
106	Cover plate gasket	265	Hex head cap screw	480	Oil tube insert
107	Socket head cap screw	266	Lockwasher	585	Oil return float valve kit
108	Lockwasher	285	Oil recirc. screw	586	Hydraulic fitting
115	Filter bracket	286	Banjo hydraulic fitting	591	Hydraulic fitting
116	Filter bracket	290	Oil return line tubing	9000	Steel socket plug
120	Exhaust filter	297	Screen	9001	Flat washer
121	O-ring	298	Slot chs. head screw	9002	Entrance elbow connector
125	Filter spring assembly	299	Rivet	9003	Fenwal temperature switch
126	Socket head cap screw	300	Motor mounting bracket	9004	Grounding washer
130	Baffle strainer	302	Lockwasher	9005	Plain washer
136	Perf. sheet metal screen	303	Hex shoulder nut	9006	Socket head cap screw
137	Hex head cap screw	306	C-face adapter flange	9007	Hex head cap screw
138	Flat washer	307	Socket head screw		
139	Lockwasher	311	Motor side coupling half		
140	Exhaust cover plate	312	Coupling insert		