


DEMA SOLENOID VALVES NORMALLY OPEN

Model O473P, O474P, & O476P

INSTALLATION INSTRUCTIONS



| NO. | PART NO. | DESCRIPTION |
|-----|----------|---|
| 1. | 41-14-7 | Coil Nut |
| 2. | 85-42-5 | Spacer Cup |
| 3. | 41-13-14 | Nameplate (Specify Model) |
| 4. | O41-9-1 | Solenoid Coil (Specify Voltage) |
| | O41-9C-1 | Optional Solenoid Coil With Conduit Boss (Specify Voltage) |
| | O41-9D-1 | Optional Solenoid Coil With DIN Connections (Specify Voltage) |
| 5. | 41-16-2 | Flange Bolt (4 Req'd) |
| 6. | 41-50 | Valve Repair Kit (Models O473P & O474P) |
| 7. | 41-50-1 | Valve Repair Kit (Model O476P) |
| 8. | 41-15-1 | Diaphragm – Buna (Models O473P & O474P) |
| | 41-15-3 | Diaphragm – Buna (Model O476P) |
| 9. | 41-12-4 | O-Ring |
| 10. | 41-4-6 | Closing Spring |