


DEMA SOLENOID VALVES NORMALLY OPEN

Model O473P, O474P, & O476P

INSTALLATION INSTRUCTIONS



NO.	PART NO.	DESCRIPTION
1.	41-14-7	Coil Nut
2.	85-42-5	Spacer Cup
3.	41-13-14	Nameplate (Specify Model)
4.	O41-9-1	Solenoid Coil (Specify Voltage)
	O41-9C-1	Optional Solenoid Coil With Conduit Boss (Specify Voltage)
	O41-9D-1	Optional Solenoid Coil With DIN Connections (Specify Voltage)
5.	41-16-2	Flange Bolt (4 Req'd)
6.	41-50	Valve Repair Kit (Models O473P & O474P)
7.	41-50-1	Valve Repair Kit (Model O476P)
8.	41-15-1	Diaphragm – Buna (Models O473P & O474P)
	41-15-3	Diaphragm – Buna (Model O476P)
9.	41-12-4	O-Ring
10.	41-4-6	Closing Spring