




10% Fixed:



Lower End Assembly
Ensemble partie basse
Unteres Ende Bausatz
Conjunto Dosificador
Conjunto Dosador



Dosmatic®

The Technology Leader In Fluid-Driven Proportional Injectors

English.....3-20

Français.....21-31

Deutsch.....32-42

Español.....43-53

Português.....54-64

Dosmatic Offices:

Dosmatic USA
1230 Crowley Circle
Carrollton, TX USA 75006
Tel: (972) 245-9765
Fax: (972) 245-9000
Email: info@dosmatic.com
www.dosmatic.com

Dosmatic Europe
20 Route de Taillefer
33450 Montussan
(Bordeaux) France
Tel: +33 (0)5 57 97 13 13
Fax: +33 (0)5 57 97 10 19
Email: info@dosmatic-europe.com

Dosmatic Asia Co., Ltd.
861/8 T.I.T. Tower Rm. 1703
Satupradit Rd.
Bangkok, Thailand 10120
Tel: +66 (0) 26 74 97 58
Fax: +66 (0) 26 74 97 59
Email: info@dosmaticasia.com

Dosmatic Latin America
Loria 398, 4° Piso Of. 16
Lomas de Zamora
CP B1832 IXH
Provincia de Buenos Aires, Argentina
Tel: +54 11 4115 1235
Fax: +54 11 4115 1481
Email: info@dosmaticla.com.ar

Dosmatic Franchise Offices:

Dosmatic Japan - Hytem
2-10 Techno Plaza
Kakamigahara City, 504 Japan
Tel: +81 (0) 583 83 0505
Fax: +81 (0) 583 83 1230
Email: info@hytem.com

Dosmatic Australia~New Zealand
P.O. Box 9074
Wyoming, NSW 2250 Australia
Tel: +61 (0) 2 43 29 09 05
Fax: +61 (0) 2 43 29 09 04
Email: doug.rowe@dosmatic-anz.com.au

Dosmatic Brazil - Plaznova
Plaznova Louveira Ind. e Com.Ltda
Estrada Francisco Pagotto 50
Bairro Capivari
Louveira-SP, Brazil 13290-000 BR
Tel: 55-19-38765403
Fax: 55-19-3886-2842
Email: plaznova@narepresentacoes.com.br