


166 Series Parts Kit List



Model Number	Complete Pump Assembly	Switch Assembly	Check Valve Assembly	1 Upper Housing	Bypass/ Non-Bypass Valve Assembly	2 Diaphragm Assembly	Drive/Impeller Assembly	Motor
166-200-36	N/A	N/A	N/A	94-176-13	N/A	94-175-05	N/A	N/A
166-200-46	N/A	N/A	N/A	94-176-13	N/A	94-175-08	N/A	N/A
166-200-56	N/A	N/A	N/A	94-176-13	N/A	94-175-06	N/A	N/A
166-200-57	N/A	N/A	N/A	94-176-13	N/A	94-175-07	N/A	N/A